		15	
Submit 3 Copies To Appropriate District State of New Me	xico	CISON ,	Form C-103
Office Euergy Minerals and Nati		<u>Alk</u>	Revised March 25, 1999
1625 N. French Dr., Hobbs, NM 88240		WELL API NO 30-015-21125	
District II 811 South First, Artesia, NM 88210 OIL CONSERVATION		5. Indicate Type of L	lease
District III 2040 South Pac		STATE 🗙	FEE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV Santa Fe, NM 8	7505	6. State Oil & Gas Fed. NM-0428854	Lease No.
2040 South Pacheco, Santa Fe, NM 87505 SUNDRY NOTICES AND REPORTS ON WELLS			Jnit Agreement Name:
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PL	JG BACK TO A		
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FO PROPOSALS.)	DR SUCH	Burton Flat Deep	Unit
1. Type of Well:		891012391-A	
Oil Well 🔲 Gas Well 🔀 Other		0. 11/ 11.21	
2. Name of Operator		8. Well No. 13	
Ocean Energy, Inc. Undes, Saladar; STrawn 3. Address of Operator		9. Pool name or W	ildcat
1001 Fannin, Suite 1600, Houston, Texas 77002		Burton-Flat-Morr	ow
4. Well Location			
Unit Letter <u>O</u> : <u>660'</u> feet from the <u>South</u> line and	1 <u>980'</u> fe	et from the <u>East</u>	line
Section 28 Township 20S	Range 28E	NMPM	Eddy County
10. Elevation (Show whether D			
GR 3219'			
11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:			
PERFORM REMEDIAL WORK 🖾 PLUG AND ABANDON 🔀	REMEDIAL WOR	.K 🖵	
TEMPORARILY ABANDON 🔲 CHANGE PLANS 🗌	COMMENCE DR	ILLING OPNS. 🔲	PLUG AND
	CASING TEST A		ABANDONMENT
PULL OR ALTER CASING UMULTIPLE COMPLETION	CEMENT JOB		
OTHER: ATTEMP RECOMPLETION	OTHER:	zivo nortinant datas i	ncluding estimated date
12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion			
of starting any proposed work) SEE RULE 1103 For Multiple	Completions: Attac	h wellbore diagram o	f proposed completion
	Completions: Attac	h wellbore diagram o	f proposed completion
or recompilation.	Completions: Attac	h wellbore diagram o	f proposed completion
or recompilation. Open. To use BCP	Completions: Attac	h wellbore diagram o	f proposed completion
or recompilation. Open. To use BCP Ocean proposes the following operations: Plug and abandon with Straw	Completions: Attac	h wellbore diagram o	f proposed completion
or recompilation. Open. To use BCP Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'.	Completions: Attac n zone test – Work to B60	h wellbore diagram o	f proposed completion
or recompilation. Open. To use BCP Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove	Completions: Attac n zone test – Work to B60	h wellbore diagram o	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer.	Completions: Attac n zone test – Work to BGO ed.	h wellbore diagram o	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 3556 cerear Place	Completions: Attac n zone test – Work to BGO ed.	h wellbore diagram o	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 3556 cerear Flog 6. Cut and pull casing at 5000'.	Completions: Attac n zone test – Work to BGO ed.	h wellbore diagram o	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. * 2556 cereal Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970'	Completions: Attac n zone test – Work to BGO ed.	h wellbore diagram o	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prover If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 2556 cerear Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'.	Completions: Attac n zone test – Work to BGO ed.	h wellbore diagram o	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. * 2556 cereal Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970'	Completions: Attac n zone test – Work to BGO ed.	h wellbore diagram o	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 35 sk cement Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'. 10. Set 35' cement plug from 5' to 40'.	Completions: Attac n zone test – Work to 8 60 ed. 8 7 40 [†] 8840	h wellbore diagram o 9 begin as soon as appr	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 35 sk cement Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'. 10. Set 35' cement plug from 5' to 40'.	Completions: Attac n zone test – Work to 8 60 ed. 8 7 40 [†] 8840	h wellbore diagram o 9 begin as soon as appr	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 35 sk cement Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'. 10. Set 35' cement plug from 5' to 40'.	Completions: Attac n zone test – Work to 8 60 ed. 8 7 40 [†] 8840	h wellbore diagram o 9 begin as soon as appr	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 35555 cement Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'. 10. Set 35' cement plug from 5' to 40'. Hereby certify that the information above is true and complete to the	Completions: Attac n zone test – Work to B 60 ed. 8940 8840 8940 8840 best of my knowled	h wellbore diagram o begin as soon as appr begin as soon as appr dge and belief.	The proposed completion for the proposed completic completion for the proposed completion for the proposed comple
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 35 sk cement Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'. 10. Set 35' cement plug from 5' to 40'.	Completions: Attac n zone test – Work to B 60 ed. 8940 8840 8940 8840 best of my knowled	h wellbore diagram o begin as soon as appr begin as soon as appr dge and belief.	f proposed completion
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove If uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 2556 cement Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'. 10. Set 35' cement plug from 5' to 40'. HETER NAME COMPARENTIAL PROVIDENT OF SIGNATURE SIGNATURE Advice Market Market TITLE	Completions: Attac n zone test – Work to B 60 ed. 8740 8940 8740 8940 Best of my knowled Regulatory Spe	h wellbore diagram o begin as soon as appr begin as soon as appr ge and belief.	Depth Proposed completion Proved. PCD - ARTESIA DATE 2/22/01
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if prove 1f uneconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. X 2555 cement Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 450' to 600'. 10. Set 35' cement plug from 5' to 40'. <i>A Mathie Name Cash. To wingst Plugging for the formation above is true and complete to the SIGNATURE Pluguing Mathieum</i> . TITLE Type or print name Jeanie McMillan	Completions: Attac n zone test – Work to B 60 ed. 8740 8940 8740 8940 Best of my knowled Regulatory Spe	h wellbore diagram o begin as soon as appr begin as soon as appr dge and belief.	Depth Proposed completion Proved. PCD - ARTESIA DATE 2/22/01
or recompilation. Ocean proposes the following operations: Plug and abandon with Straw 1. Set production equipment. 2. Perforate and test Strawn zone from 10,274-10,586'. 3. Determine economic potential and return to production if proventing unconomical continue with step No. 4. 4. Pull tubing and packer. 5. Set CIBP @ 10,200' with 50' cement. * 2555 cereof Plug 6. Cut and pull casing at 5000'. 7. Set 200' cement plug from 4900' to 5100'. 8. Set 300' cement plug from 2670' to 2970' 9. Set 150' cement plug from 5' to 600'. 10. Set 35' cement plug from 5' to 40'. * Matcher Name Cash To Matcher Plugging of the structure of the structur	Completions: Attac n zone test – Work to B 60 ed. 8740 8940 8740 8940 Best of my knowled Regulatory Spe	h wellbore diagram o begin as soon as appr begin as soon as appr ge and belief.	Depth Proposed completion Proved. PCD - ARTESIA DATE 2/22/01

APPPROVED BY <u>Mule Stufflifiell</u> Conditions of approval, if any: