

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

NM OIL CONS COMMISSION

Drawer DD

Artesia, NM 88210

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-13968

6. If Indian, Allottee or Tribe Name

N/A

7. If Unit or CA, Agreement Designation

N/A

8. Well Name and No.

Huber IA Federal #2

9. API Well No.

30-015022217

10. Field and Pool, or Exploratory Area

Boyd Canyon Permo Penn

11. County or Parish, State

Eddy, NM

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION

(505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FSL & 1270' FEL, SESE, Sec. 15-T21S-R21E, NMPM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion or well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Notify the BLM Carlsbad prior to commencing work. Must use 9.0 ppg mud between plugs.
2. Set 35' more cement on top of existing CIBP at 6900'.
3. Set 100' cement plug from 5764-5864'. WOC and tag.
4. Set 100' cement plug from 3528-3628'. WOC and tag.
5. Cut and pull 5-1/2" casing. Top of cement at 3112' by CBL.
6. Set 100' cement plug across 5-1/2" casing stub. WOC and tag.
7. Set 100' cement plug from 1253-1353' (across 8-5/8" casing shoe). WOC and tag.
8. Set 100' cement plug from 210 - 310' (across 13-3/8" casing shoe).
9. Set 50' cement plug at surface and install P&A marker.

\* Verbal approval 10-17-94 per telephone conversation between Rex Gates and Joe Lara (BLM).

14. I hereby certify that the foregoing is true and correct

Signed Randy Klein (by Amy Lapan)

Title Production Clerk

Date 10-17-94

(This space for Federal or State office use)

Approved by \_\_\_\_\_

Title \_\_\_\_\_

Date 11/14/94

Conditions of approval, if any:

