

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE  
(Either instructions on reverse side)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR  
Manzano Oil Corporation

3. ADDRESS OF OPERATOR  
P.O. Box 2107, Roswell, NM 88202-2107

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface ☒  
990' FNL and 1650' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, MT, GK, etc.)  
3360' GL

5. LEASE DESIGNATION AND SERIAL NO.  
NM-02295

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Gallo Federal

9. WELL NO.  
1

10. FIELD AND POOL, OR WILDCAT  
Wildcat, Delaware

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 11, T20S, R27E

12. COUNTY OR PARISH  
Eddy

13. STATE  
New Mexico

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- Spot 35' of CMT on existing CIBP @ 3880' unless you have already done so.
1. Set 150' cement plug from 2800' back to 2650'. [TAG PLUG]
  2. Set 100' cement plug at 8-5/8" casing shoe from 300' back to 400'.
  3. Set 10 sks cement plug at surface.
  4. Install dry hole marker
  5. All space between cement plugs to be filled w/10 ppg mud.

18. I hereby certify that the foregoing is true and correct

SIGNED Laura J. King

TITLE Production Department

DATE 7/10/91

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE 7/11/91

CONDITIONS OF APPROVAL, IF ANY:

\*NOTE: Please contact BLM @ (505) 887-6544 in sufficient time for a representative to witness P&A operation.

\*See Instructions on Reverse Side