

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

OIL CONS COMMISSION
Artesia, NM 88210

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION (505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FNL & 660' FEL of Section 33-T21S-R30E (Unit H, SENE)

5. Lease Designation and Serial No.

NM-53232

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Kaleidoscope AKO Fed #1

9. API Well No.

30-015-27038

10. Field and Pool, or Exploratory Area

Cabin Lake Delaware

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

If workover is not successful, propose to plug and abandon as follows:

1. Set a CIBP at 4200' and cap with 35' of cement.
2. Spot a 100' cement plug across the 8-5/8" casing shoe at 3357'.
3. Perforate the 5-1/2" casing at 264'. Set a cement retainer at 164'.
4. Sting into cement retainer and pump cement until cement circulates to surface.
5. Install regulation abandonment marker.

NOTIFY BLM-CARLSBAD (505-887-6544) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

RECEIVED

OCT 20 1995

OIL CON. DIV.
DIST. 2

14. I hereby certify that the foregoing is true and correct

Signed

Rudy Kline

Title Production Clerk

Date Sept. 21, 1995

(This space for Federal or State office use)

Approved by

(ORIG. SCD.) JOE G. LARA

Title

PETROLEUM ENGINEER

Date

10/18/95

Conditions of approval, if any:

See attached. Also spot 50' plug @ surface.