

## NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

## MISCELLANEOUS NOTICES

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature of Notice by Checking Below

|   |   |  |  |   |  |
|---|---|--|--|---|--|
| NOTICE OF INTENTION<br>TO CHANGE PLANS  |   | NOTICE OF INTENTION TO<br>TEMPORARILY ABANDON WELL |  | NOTICE OF INTENTION<br>TO DRILL DEEPER  |  |
| NOTICE OF INTENTION<br>TO PLUG WELL     | X | NOTICE OF INTENTION<br>TO PLUG BACK                |  | NOTICE OF INTENTION<br>TO SET LINER     |  |
| NOTICE OF INTENTION<br>TO SQUEEZE       |   | NOTICE OF INTENTION<br>TO ACIDIZE                  |  | NOTICE OF INTENTION<br>TO SHOOT (Nitro) |  |
| NOTICE OF INTENTION<br>TO GUN PERFORATE |   | NOTICE OF INTENTION<br>(OTHER)                     |  | NOTICE OF INTENTION<br>(OTHER)          |  |

OIL CONSERVATION COMMISSION  
SANTA FE, NEW MEXICOArtesia, New Mexico  
(Place)Sept. 8, 1953  
(Date)

Gentlemen:

Following is a Notice of Intention to do certain work as described below at the.....

David C. Saikin Magruder-State Well No. 1 in G  
(Company or Operator) (Unit)

SW 1/4 NE 1/4 of Sec. 28, T. 23S, R. 26E, NMPM., Wildcat Pool  
(40-acre Subdivision)

Eddy County.

### FULL DETAILS OF PROPOSED PLAN OF WORK

(FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS)

Run tubing to 1800 feet and load hole to surface with Aquagel  
Spot 30 ft cement plug 1770 to 1800 ft.  
Spot 20 ft. cement plug 1300 to 1320 ft. below base of salt  
Spot 20 ft. cement plug 1140 to 1160 ft. above top of salt  
Spot 50 ft. cement plug 525 to 575 ft. in and below 8-5/8" casing cemented at 555 ft. with 50 sacks.

If rancher takes this well over as a water well, this plugging job will be complete after cutting and pulling 8-5/8" casing. If rancher does not wish to take over, must set bridge & 5 sacks cement at 100 ft; fill hole to surface and set regulation marker. In either case the slush pits must be filled and location cleared of all junk. If rancher takes over he must also file Form C-103 in triplicate, assuming all responsibility for final plugging of well.

Approved....., 19.....  
Except as follows:

Company or Operator

By.....

Position.....

Send Communications regarding well to:

Approved  
OIL CONSERVATION COMMISSION

By.....

Name.....

Title.....

Address.....