

N. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

NOV 20 1978

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT DEPTH. USE APPLICATION FOR PERMIT - FORM C-101 FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-4101		
6. C.C.C. ARTESIA OFFICE		
7. Unit Agreement Name		
8. Farm or Lease Name South Rock Tank Gas Co.		
9. Well No. 1		
10. Field and Pool, or Wildcat Wildcat - Bone Spring		
11. Location of Well: UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>2</u> TOWNSHIP <u>24-S</u> RANGE <u>24-E</u> N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.) 3979 KB		17. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Evaluated well and determined it is not commercially productive. Propose to P x A well using the following procedure. Pull tubing and remove well head. Cut and pull approximately 3900' 5 1/2" casing. Spot a 100 Class C cement plug 3950' to 3850', 50 ft. in and out of casing stub.

*Spot -100' Class C cement plug 2829' - 2729', 50' in and out 9 5/8" casing shoe at 2779'. Spot a 20' Class C cement plug at surface. Erect P X A marker. Clean and level location.

* Note: If unable to pull 5 1/2" casing below 2779', well spot only a cement plug at the casing stub.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Henris Evans TITLE Assist. Admin. Analyst DATE 11-15-78

APPROVED BY W.A. Gressett TITLE SUPERVISOR, DISTRICT II DATE NOV 21 1978

CONDITIONS OF APPROVAL, IF ANY: Stub + shoe plugs be tagged

O & 4 NMOC-D-A 1-Susp 1-Div 1-DE