

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

RECEIVED NEW MEXICO OIL CONSERVATION COMMISSION

OCT 17 1978

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-4541
7. Unit Agreement Name
8. Farm or Lease Name Sulphate Aunt
9. Well No. 1
10. Field and Pool, or Wildcat Wildcat
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-
2. Name of Operator Corinne Grace
3. Address of Operator P. O. Box 1418, Carlsbad, New Mexico 88220
4. Location of Well UNIT LETTER C 1980 FEET FROM THE West LINE AND 660 FEET FROM THE North LINE, SECTION 3 TOWNSHIP 24S RANGE 27E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3173.2

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

There is 16" casing set in this hole to a depth of 380'
Hole size out of casing 12 1/4"

T.D. 1200' / 333

Plan to plug and abandon as follows:

Run tubing to T.D. load with mud Plug 1100' -1200' 100 sks
350- 450' 100 sks. tag
Go down backside (if possible) with 1" and put 100 sks and tag in shoe
Set surface plug w/20 sks
Set marker

Run 2" Tubing to 1208' Pull 380'-16" Casing - Set 100 sk Class C Plug
@ 1208 Pull Tubing to 450' set 100 sk Class C Plug - Set 20 sk
Class C Surface Plug
By B.W. Weaver

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Granita Jones Wildberger TITLE Agent DATE 10/16/78

APPROVED BY W.A. Gressett TITLE _____ DATE 10-18-78

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

Plugging