

Submit 3 Copies To Appropriate District

Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Ave., Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103

Revised March 25, 1999

WELL API NO.
30-015-22352

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
VB0522

7. Lease Name or Unit Agreement Name:

Red Bluff State

8. Well No. 1

9. Pool name or Wildcat
Willow Lake/Bone Springs

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK OR TO RE-ENTER A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other

2. Name of Operator Purvis Operating Co. /

3. Address of Operator
P O Box 11006, Midland, TX 79702-8006

4. Well Location

Unit Letter F : 1980 feet from the North line and 1980 feet from the West line

Section 36 Township 24S Range 27E NMPM Eddy County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Set 35 sk cement plug from ⁶⁵⁰⁰6300' back to ⁶⁴⁰⁰6200' - TAG

2. Set 35 sk cement plug from 4200' back to 4100' - TAG

3. Set 35 sk cement plug across 13 3/8" shoe (50' in and 50' out) - TAG ← 35 sk plug @ 2120' - TAG

4. ~~Set 35 sk cement plug across 20" shoe (50' in and 50' out)~~

5. ~~Set 10 sks surface plug~~

6. Install Dry Hole marker

inside
Perf. csq @ 238' - Place 100' of cmt. inside
Outside of csq. 138' - 238' - TAG
Perf csq. @ 60' - circ. cmt 0' - 60'

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Donnie E. Brown TITLE Field Rep P.E. DATE October 9, 2002

Type or print name Donnie E. Brown

Telephone No. 915-682-7346

(This space for State use)

APPROVED BY [Signature] TITLE Field Rep DATE OCT 25 2002

Conditions of approval, if any:

Notify OCD 24 hrs. prior to any work done

Salt gel mud consisting of 10#
Brine W/25# of gel per bbl
must be placed between each plug