

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 208
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.O.S.	
LAND OFFICE	
OPERATOR	<input checked="" type="checkbox"/>

MAR 26 1980

O. C. D.

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-776	
7. Unit Agreement Name	
8. Farm or Lease Name	
Eddy "GN" State Com	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Undes. Strawn	
12. County	
Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPLY OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator
GULF OIL CORPORATION
3. Address of Operator
P. O. Box 670, Hobbs, NM 88240
4. Location of Well
UNIT LETTER <u>G</u> , <u>1880</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>28</u> TOWNSHIP <u>23S</u> RANGE <u>26E</u> N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)

3325' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

10,815' PB Set 5" CIBP @ 10,400'. Circ hole w/abandonment mud. Cap CIBP w/35' cmt to test to 1000#. Top 5" liner w/35 sack cmt plug. Cut 7-5/8" csg @ 4500' & pull 7-5/8" csg. Set cmt plugs from 4550'-4650', 2675'-2775', 1957'-2057', 240'-340' & a 50' surf plug. Leave starting head on & pull off anything else. Place dry hole marker on well. RD PU. Clean & clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED N. F. Sikes, Jr. TITLE Area Engineer DATE

APPROVED BY W. A. Gressitt TITLE SUPERVISOR, DISTRICT DATE APR 8 1980

CONDITIONS OF APPROVAL, IF ANY: 7 5/8" stub & 10 3/4" shoe plugs to be tagged