

COPIES RECEIVED	3
TRIBUTION	
T FE	1
P LE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

JUL 24 1981

O. C. D.
ARTS & CRAFTS OFFICE

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator HNG Oil company /	8. Farm or Lease Name Kelly 5
3. Address of Operator P. O. Box 2267, Midland, Texas 79702	9. Well No. 2
4. Location of Well UNIT LETTER <u>LC</u> 1650 FEET FROM THE <u>West</u> LINE AND 990 FEET FROM THE <u>North</u> LINE, SECTION <u>5</u> TOWNSHIP <u>23S</u> RANGE <u>28E</u> NMPM.	10. Field and Pool, or Willcat Herradura Bend Delaware
15. Elevation (Show whether DF, RT, GR, etc.) 3023' GR	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set a 5-1/2" cement retainer at 2400' and squeeze the Delaware perms from 2465' - 2471' with 50 sacks Class H cement. Leave 25 feet cement on top of the retainer.
- 2) Spot 25 sacks Class H cement from 550' to 350'.
- 3) Spot 15 sacks Class H at the surface.
- 4) Cut off head and weld on plate and install dry-hole marker.

There will be no casing recovered from this well.

* Run Bond Log to determine top of Cement behind 5 1/2" casing and contact this office for further plugging approval

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Betty Seldon TITLE Regulatory Clerk DATE 7-23-81

APPROVED BY W.A. Gressitt TITLE SUPERVISOR, DISTRICT II DATE JUL 29 1981

CONDITIONS OF APPROVAL, IF ANY:

* as noted

Next time to withdraw

Plugging