

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	<input checked="" type="checkbox"/>
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

OIL CONSERVATION DIVISION  
RECEIVED BY O. BOX 2088  
SANTA FE, NEW MEXICO 87501  
APR -4 1985  
O. C. D.  
ARTESIA, NEW MEXICO

Form C-103  
Revised 10-1-73

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator DINERO OPERATING COMPANY	8. Farm or Lease Name Giovengo
3. Address of Operator P. O. DRAWER 10505, MIDLAND, TEXAS 79702	9. Well No. 1
4. Location of Well UNIT LETTER L, 1980 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 25, TOWNSHIP 23-S, RANGE 28-E, N.M.P.M.	10. Field and Pool, or Wildcat Und. Delaware
15. Elevation (Show whether DF, RT, GR, etc.) 2991'	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Current Status: Drilled TD 8100', plug back T.D. 8047'. Plug back with CIBP at 6520' with 20' cement. Plug back T.D. 6495'. Top of perf. at 6013'.

We propose as follows:

1. Set CIBP at 5913' with 25 sx. cement on top.
2. Set cement plug (25 sx.) at 2434'. Across bottom of 8 5/6 casing.
3. Set cement plug (25 sx.) at 1350'.
4. Set cement plug (40sx.) at 450' in 8 5/8 casing, across 13 3/8 casing.
5. Set 10 sacks at surface.
6. Make ID marker of 4 1/2 casing. Will try to cut & pull 5 1/2 at 1000.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Lavanda Nerman TITLE Production Supervisor DATE 4/3/85

APPROVED BY Les A. Clements TITLE Supervisor District II DATE JUN 25 1985  
CONDITIONS OF APPROVAL, IF ANY: