

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	<input type="checkbox"/>
LAND OFFICE	<input type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

JUN 29 1983

O. C. D.

ARTS & CRAFTS OFFICE

5a. Indicate Type of Lease State: <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Grandi
9. Well No. 1
10. Field and Pool, or Wildcat Wolfcamp
12. County Eddy

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT ADJACENT PROPERTY. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/>	GAS WELL <input checked="" type="checkbox"/>	OTHER-
2. Name of Operator V. H. Westbrook ✓		
3. Address of Operator P.O. Box 2264, Hobbs, NM 88240		
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>22</u> TOWNSHIP <u>22S</u> RANGE <u>27E</u> N.M.P.M.		

15. Elevation (Show whether DF, RT, GR, etc.)  
3097.1 ft

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

6-27-83 Load hole w/ brine - POH w/ Packer - Pick-up Rtv. B.P. & Packer - Go back in hole - Spot 500 gals 15%HCL Acid & breakdown perfs at 9826 thru 9850. Swab back acid - Treat w/ 2500 gals 15% HCL - Test Well  
Move BP above bottom perfs. and perf W.C. @ 9535 to 37, 9542 to 46, 9622 to 24 w/ 2 shts per ft. Spot 500 gals 15% HCL & break down - Swab back and treat w/ 1500 gals 15% HCL - Swab & Test zone.  
Move Bridge plug above 9500' - Spot 500 gals. 15% acid on perfs at 9003 to 9047. Break down formation - Swab back and treat w/ 2500 gals. 15% HCL. Swab back & test zone.

Verbally approved by Mike Williams

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>V. H. Westbrook</u>	TITLE <u>Owner</u>	DATE <u>6-27-83</u>
	Original Signed By <u>Leslie A. Clements</u> Supervisor District II	DATE <u>JUN 29 1983</u>
APPROVED BY _____	TITLE _____	
CONDITIONS OF APPROVAL, IF ANY:		