

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well

☐ Oil Well ☐ Gas Well ☐ Other SWD

2. Name of Operator

Hanson Operating Company, Inc.

3. Address and Telephone No.

P.O. Box 1515, Roswell, New Mexico 88202-1515 (505) 622-7300

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

NW 1/4 SE 1/4 Unit J 1650' FSL & 2310 FEL Sec. 25 T 26S R 31E

5. Lease Designation and Serial No.

LC-068282-B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Hanson Federal #7

9. API Well No.

30-015-05823

10. Field and Pool, or Exploratory Area

North Mason Delaware

11. County or Parish, State

Eddy

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recomplenon
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recomplenon Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Hanson Operating Company, Inc., is planning to plug and abandon the above well in the following manner:

- 1.) Set a CIBP at 4130' and cap with 35' of cement to isolate the Delaware open hole from 4177-4185.
- 2.) Set a 150' cement plug at the top of the salt 1890', 75' below and 75' above.
- 3.) Set a 150' cement plug at the 8 5/8- 5 1/2 casing shoe (935') 75' below and 75' above.
- 4.) Set a 50' cement plug at surface.
- 5.) Remove all equipment and install dry hole marker. All cement plugs will be placed with 9.5# mud ladden fluid. All cement plugs will Class C cement.

14. I hereby certify that the foregoing is true and correct

Signed

Betsy Speer

Title Production Analyst

Date 9-6-95

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations in any matter within its jurisdiction.

*See Instruction on Reverse Side