

STATE OF NEW MEXICO  
OIL AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

OIL CONSERVATION DIVISION

P. O. BOX 1088

SANTA FE, NEW MEXICO 87501

O+6 - NMOCD-Drawn DD, 1 - Foreman CK  
Artesia, NM 88210  
1 - Engr. Jim 1 - File  
1-Laura Richardson-Midland

Form C-103  
Revised 10-1-73

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-920

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- SWD well
2. Name of Operator Getty Oil Company ✓
3. Address of Operator P.O. Box 730 Hobbs, NM 88240
4. Location of Well UNIT LETTER C 1650 FEET FROM THE West LINE AND 660 FEET FROM THE North LINE, SECTION 36 TOWNSHIP 26S RANGE 31E NMPM.

RECEIVED BY  
SEP 09 1983  
O. C. D.  
ARTESIA, OFFICE

7. Unit Agreement Name
8. Farm or Lease Name Eddy State AG-A
9. Well No. 2
10. Field and Pool, or Wildcat N. Mason Delaware
12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We proposed to P&A this well as discussed with Mr. Larry Brooks NMOCD on August 2, 1983 as follows:

1. Set CIBP at + 4100 with 100' cement on top.
2. Set 10 sx plug 1717-1817'.
3. Run cement bond 2000-0'. If cement top is below 918', perforate 2 holes @ + 970 and tie onto 5 1/2" csg. and cement casing and annulus, otherwise a 10 sx plug will be set 970-870' in the 5 1/2" csg. + Tag
4. Set 10 sx. surface plug.
5. Install dry hole marker.
6. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dale R. Crockett TITLE Area Superintendent DATE September 7, 1983

APPROVED BY Mike Walker TITLE OIL AND GAS INSPECTOR DATE SEP 12 1983

CONDITIONS OF APPROVAL, IF ANY: \* M. D. M. 75 54 Notify N.M.O.C.C. in sufficient time to witness Plugging