

DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Budget Bureau No. 40-100
 5. LEASE, DESIGNATION AND SERIAL NO.

HW 0456187

6. IF INDIAN, ALLIGEE OR TRUST, ETC.

SUNDRY NOTICES AND REPORTS ON WELLS

(Use back of this form for notices to well owners to discontinue or shut back to a different reservoir.
 Use SEPARATE FORM FOR PERMITS for such purposes.)

RECEIVED

1. NAME OF OPERATOR City Service Oil Company		2. DATE OCT 1 1973		7. UNIT AGREEMENT NAME	
3. ADDRESS OF OPERATOR Box 4906 - Midland, Texas 79701		8. FARM OR LEASE NAME Government Q		9. WELL NO. 1	
4. LOCATION OF WELL (Show location clearly and in accordance with any applicable regulations. See also Section 17, General Instructions.) At surface: 1900' PSL & 660' FWL of Sec. 26-T25S-R24E, Eddy County, New Mexico.		10. FIELD AND POOL, OR WILDCAT Undes. Washington Ranch Morrow		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 26-T25S-R24E	
14. PERMIT NO.		15. ELEVATIONS (Show whether DE, RT, G, etc.) 3675' GR.		12. COUNTY OR PARISH Eddy	
				13. STATE N. Mexico	

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Re-completion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and times pertinent to this work.) *

T.D. 7200 Shale. Prep to plug and abandoned. This well was drilled to a T.D. of 7200' and we proposed to plug and abandon in the following manner:

1. Spot a 50 sx cement plug @ approx. 6900' - 6700'.
2. Spot a 25 sx cement plug @ approx. 5750' - 5650'.
3. Displace a 50 sx cement plug @ approx. 3800' - 3700'.
4. Displace a 50 sx cement plug @ approx. 2300' - 2200'.
5. Displace a 60 sx cement plug @ approx. 940' - 840' (1/2 in and 1/2 out of 13-3/8" shoe set @ 899').
6. Displace a 15 sx cement surface plug @ approx. 20 - 0 with a 4" dry hole marker.
7. Clean location of all equipment and debris and notify your office for final inspection.

This proposed plugging procedure was given oral approval by Mr. Jim Knauf (USGS Artesia Office).

RECEIVED

SEP 21 1973

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

I, the undersigned, declare the foregoing is true and correct.

SIGNED Schulder TITLE Region Oper. Mgr. DATE Sept. 19, 1973

(Use space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF THE FEDERAL GOVERNMENT

APPROVED

SEP 20 1973

W. L. BEERHORN

ARTESIA DISTRICT ENGINEER

*See Instructions on Reverse Side