

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION **RECEIVED**

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

OCT 06 '87

O. C. D.
ARTESIA OFFICE

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
LG-1171	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	Flower Draw Unit
3. Address of Operator	8. Farm or Lease Name
P.O. Box 3178, Midland, TX 79702	Flower Draw Unit
4. Location of Well	9. Well No.
UNIT LETTER <u>I</u> 1980 FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM	3
THE <u>East</u> LINE, SECTION <u>3</u> TOWNSHIP <u>26S</u> RANGE <u>28E</u> NMPM.	10. Field and Pool, or Wildcat
	Und. Delaware
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
2951' KB 2937' GR	Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Approximate starting date: 11-1-87

Proposed plugging procedure w/perfs @ 2844-2856':

1. Set 100' plug @ 2800' & tag
2. Cut 4 1/2" off @ 2000'. Set 100' plug @ 2000'. + Tag
3. Set 100' plug @ 400' if any 8-5/8" is recovered. in + out of 8 5/8"
4. Set 10 sx plug @ surface w/marker.
5. Clean location.

Mud will be used between all plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Larry Brown TITLE Agent DATE 9-28-87

APPROVED BY Mike Williams TITLE OIL AND GAS INSPECTOR DATE OCT 07 1987

CONDITIONS OF APPROVAL, IF ANY:

Minimum 2 1/2" sx plugs

Notify N.M.C.D. in sufficient time to witness