

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN 1 REPLICATE*
(Other instructions on re-
verse side)

copy to SF
Form approved,
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Dry Hole		5. LEASE DESIGNATION AND SERIAL NO. NM 8664	
2. NAME OF OPERATOR Anadarko Production Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR 310 N. Willis St. - Abilene, Texas 79603		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1650' FWL & 1820' FSL, Sec. 34-T21S-R24E, Eddy County, New Mexico.		8. FARM OR LEASE NAME Federal "AE"	
14. PERMIT NO. -	15. ELEVATIONS (Show whether DF, RT, CR, etc.) 4025' K3	9. WELL NO. 1	10. FIELD AND POOL, OR WILDCAT land Indian Basin <i>by sec. Perm</i>
		12. COUNTY OR PARISH Eddy	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SLOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

PROPOSAL TO ABANDON:

- Fill hole with mud.
- Set CIBP @ 7840' in 5 1/2" Casing.
- Dump 5 sks. cement 7805'-40'
- Shoot off 5 1/2" casing @ 7000' and pull casing.
- Pump 25 sks. cmt. 6950'-7050'
- Pump 25 sks. cmt. 5500'-5600'
- Pump 25 sks. cmt. 4000'-4100'
- Pump 25 sks. cmt. 2750'-2850'
- Pump 10 sks. cmt. in top of 8-5/8" casing & erect dry hole marker.

Verbal approval was obtained from Mr. Knauf by telephone to plug and abandon.

18. I hereby certify that the foregoing is true and correct

SIGNED William R. Banks TITLE District Production Supt. DATE Nov. 7, 1967

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____
CONDITIONS OF APPROVAL, IF ANY:

APPROVED

RECEIVED

NOV 19 1967

*See instructions on Reverse Side

NOV 21 1969

D. C. C.
ARTESIA, OFFICE

R. L. BEEKMA
ACTING DISTRICT SUPERVISOR