

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB No. 1004-0135
Expires November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or reenter an abandoned well. Use Form 3160-3 (APD) for such proposals.

5. Lease Serial No.

NM0560223

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or N

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Running Horse Production Company

3a. Address

PO Box 737, Ignacio, CO 81137

3b. Phone No. (include area code)

970-563-0145

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1190' FNL & 1190' FEL, Section 19, T26N-R12W

8. Well Name and No.

Frew Federal 5

9. API Well No.

30-045-22476

10. Field and Pool, or Exploratory Area

Waw Fruitland Sand PC

11. County or Parish, State

San Juan, New Mexico

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☒ Final Abandonment Notice

TYPE OF ACTION

- | | | | |
|---|--|--|---|
| <input type="checkbox"/> Acidize | <input type="checkbox"/> Deepen | <input type="checkbox"/> Production (Start/Resume) | <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Alter Casing | <input type="checkbox"/> Fracture Treat | <input type="checkbox"/> Reclamation | <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Casing Repair | <input type="checkbox"/> New Construction | <input type="checkbox"/> Recomplete | <input type="checkbox"/> Other |
| <input type="checkbox"/> Change Plans | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Temporarily Abandon | |
| <input type="checkbox"/> Convert to Injection | <input type="checkbox"/> Plug Back | <input type="checkbox"/> Water Disposal | |

13. Describe Proposed or Completed Operations (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and so forth. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed (even if Testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator determined that the site is ready for final inspection.)

Running Horse Production Company proposes to plug and abandon this well according to the attached prognosis.

RECEIVED

2003 JUN 19 PM 5:00

070 Farmington, NM



14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Robert J. Voorhees

Title

Vice President Engineering & Development

Signature

[Signature]

Date

June 5, 2003

THIS SPACE FOR FEDERAL OR STATE USE

Approved by

Original Signed: Stephen Mason

Title

Date

JUN 27 2003

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on reverse)

NMOCGD

June 5, 2003

Running Horse Production Company

P&A Procedures for Frew Federal #5

Location: NE/4 Sec 19, T26N-R12W, San Juan County, NM

Field: Waw Fruitland Sand PC

Surface: Navajo

Lease: NM 0560223

Elevation: 6086'

Production String: 4 1/2" @1301'

PBTD: 1165'

Procedure:

1. MIRU service unit.
2. NU 2 3/8" relief line. Blow well down and kill with water if necessary.
Laydown tubing.
3. Connect cement truck directly to 4 1/2" casing and fill casing with ~~40~~^{increased} ~~sq~~ (47 cu ft) of Class H cement with 1/4#/sk celloflake. Pump cement until tubing stands full.
4. Cut off wellhead and install dry hole marker. Reclaim location as per BLM specifications.