Submit 3 Copies To Appropriate District				
pagning a Cobies to Whitchingto District	State of New M	lexico		Form C-103
Office District I	Energy, Minerals and Natu	ıral Resources		May 27, 2004
1625 N. French Dr., Hobbs, NM 87240			WELL API NO.	
District II 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION		30-039-21170	
District III	1220 South St. Francis Dr.		5. Indicate Type of Lease	
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM	87505	STATE	J FEE ☑
1220 S. St. Francis Dr., Santa Fe, NM 87505	2000	728 63 80 3117	6. State Oil & Gas	s Lease No.
SUNDRY NOTIC	ES AND REPORTS ON WE	LLS ²² VA	7. Lease Name or	Unit Agreement Name:
(DO NOT USE THIS FORM FOR PROPODIFFERENT RESERVOIR. USE "APPLIC	SALS TO DRILL OR TO ÉÉPEN ATION FOR REPMIT! (FORM C.	OR PLANSBACK TO A	Lindrith Unit	Ŭ
PROPOSALS.)				
1. Type of Well:	E OL	CONS.DW.	8. Well Number	
Oil Well Gas Well X	Other ⊱	DIST. 8 CO		36
2. Name of Operator			9. OGRID Numbe	į.
Energen Resources Corporat 3. Address of Operator	ion (4)	2/ C/ C 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/ 2/	10. Pool name or	Wildoot
2198 Bloomfield Highway,	Farmington NM 87401	ALA	South Blanco P.	
4. Well Location	ratificati, iti 0/401		poudi maios r.	romen curitis
I Imit I attan	15501 foot from the No	and line and	9501 5-45-	matha Woot live
Unit Letter E::	1550' feet from the No	line and	eet fro	m the West line
Section 21	Township 24N	Range 02W	NMPM	County Rio Arriba
	11. Elevation (Show whether	DR, RKB, RT, GR, et	c.)	
		.53' GL		A CONTRACTOR OF THE SECOND
Pit or Below-grade Tank Application				
Pit type Depth to Groundwater				face water
Pit Liner Thickness: mil	Below-Grade Tank: Volume	bls; Construction	on Material	
		A. Nintiira at Nintiaa	Danart arfitha	r I loto
NOTICE OF INTE	PLUG AND ABANDON	SUB REMEDIAL WORK	SEQUENT RE	PORT OF: ALTERING CASING
NOTICE OF INTE	ENTION TO:	SUB	SEQUENT RE	PORT OF:
NOTICE OF INTE	ENTION TO: PLUG AND ABANDON	SUB REMEDIAL WORK	SEQUENT RE	PORT OF: ALTERING CASING PLUG AND X
NOTICE OF INTERPERSON TEMPORARILY ABANDON	ENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND	SEQUENT RE	PORT OF: ALTERING CASING PLUG AND X
NOTICE OF INTERPRETATION TEMPORARILY ABANDON PULL OR ALTER CASING	ENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION I operations. (Clearly state all p	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give	SEQUENT RE	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date
NOTICE OF INTERPERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING OTHER: 13. Describe proposed or completed of starting any proposed work).	ENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION I operations. (Clearly state all p SEE RULE 1103. For Multip	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach	SEQUENT RE	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion
NOTICE OF INTERPRETATION PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING OTHER: 13. Describe proposed or completed of starting any proposed work). or recompletion. Energen Resources plugged	ENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION I operations. (Clearly state all p SEE RULE 1103. For Multip	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach	SEQUENT RE	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion
NOTICE OF INTERPRETATION PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING OTHER: 13. Describe proposed or completed of starting any proposed work). or recompletion. Energen Resources plugged	ENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION I operations. (Clearly state all p SEE RULE 1103. For Multip	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach	SEQUENT RE	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion
NOTICE OF INTERPRETATION PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING OTHER: 13. Describe proposed or completed of starting any proposed work). or recompletion. Energen Resources plugged	ENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION I operations. (Clearly state all p SEE RULE 1103. For Multip and abandoned the Lindri	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach	SEQUENT RE ING OPNS. e pertinent dates, inc. n wellbore diagram of the grand of	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion attached plugging
NOTICE OF INTER PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completed of starting any proposed work). or recompletion. Energen Resources plugged proedure.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION I operations. (Clearly state all p SEE RULE 1103. For Multip and abandoned the Lindri bove is true and complete to the	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach th Unit #86 on 11/3	SEQUENT RE ING OPNS. e pertinent dates, inc. n wellbore diagram of the grand of	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion attached plugging
NOTICE OF INTER PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completed of starting any proposed work). or recompletion. Energen Resources plugged proedure. I hereby certify that the information at grade tank has been will be constructed or constructe	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Operations. (Clearly state all p SEE RULE 1103. For Multip and abandoned the Lindri bove is true and complete to the closed according to NMOCD guideling TI' E-	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach th Unit #86 on 11/3	SEQUENT RE ING OPNS. e pertinent dates, inc. wellbore diagram of the grand belief. I further the control of	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion attached plugging recrtify that any pit or below- ernative OCD-approved plan DATE 12/01/05
NOTICE OF INTERPERSON REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DOTHER: 13. Describe proposed or completed of starting any proposed work). Or recompletion. Energen Resources plugged procedure. I hereby certify that the information algrade tank has been will be constructed or or SIGNATURE. Type or print name Vicki Donagher.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Operations. (Clearly state all p SEE RULE 1103. For Multip and abandoned the Lindri bove is true and complete to the closed according to NMOCD guideling TI' E-	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach th Unit #86 on 11/3 e best of my knowledge les X , a general permit TLE Regulator mail address:	e pertinent dates, income wellbore diagram of the wellbore diagram of the and belief. I further or an (attached) altery Analyst vdonaghe@energe Tele	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion attached plugging recrtify that any pit or belowernative OCD-approved plan DATE 12/01/05 n. com phone No. 505.325.6800
NOTICE OF INTER PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completed of starting any proposed work). or recompletion. Energen Resources plugged procedure. I hereby certify that the information algrade tank has been will be constructed or of SIGNATURE. Type or print name Vicki Donagher.	ENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION I operations. (Clearly state all p SEE RULE 1103. For Multip and abandoned the Lindri bove is true and complete to the closed according to NMOCD guideling TI' E.	SUB REMEDIAL WORK COMMENCE DRILLI CASING TEST AND CEMENT JOB OTHER: ertinent details, and give le Completions: Attach th Unit #86 on 11/3 e best of my knowledge les X , a general permit TLE Regulator mail address:	e pertinent dates, income wellbore diagram of the wellbore diagram of the and belief. I further or an (attached) altery Analyst vdonaghe@energe Tele	PORT OF: ALTERING CASING PLUG AND ABANDONMENT Cluding estimated date of proposed completion attached plugging r certify that any pit or below- ernative OCD-approved plan DATE 12/01/05 n. com

Note-LANDOWNER GAS TAP-Edge Lo. (6-12-06 has been Remark) &

A-PLUS WELL SERVICE, INC.

P.O. BOX 1979 Farmington, New Mexico 87499 505-325-2627 * fax: 505-325-1211

Energen Resources Corporation Lindrith #86

November 30, 2005 Page 1 of 1

1550' FNL & 850' FWL, Section 21, T-24-N, R-2-W Rio Arriba County, NM Lease Number: Fee Lease API #30-039-21170

Plug and Abandonment Report

Notified BLM / NMOCD on 11/23/05

Work Summary:

- 11/28/05 MOL. RU. Check well pressures: casing 200#; bradenhead open. Blow down well. Round trip gauge ring to 3053'. RIH with 2.875" PlugWell CIBP; set at 3053'. SDFD.
- 11/ 29/05 Open well; no pressures. Tally, rabbit, PU and RIH with 1.25" IJ workstring; tag CIBP at 3053'. Establish circulation with 19 bbls of water. Pressure test casing to 500#. Plug #1 with CIBP at 3053', spot 15 sxs Type III cement (20 cf) inside casing from 3053' up to 2444' to cover the Pictured Cliffs interval and the Fruitland, Kirtland and Ojo Alamo tops.

TOH with tubing. Perforate 2 bi-wire squeeze holes at 1305'. Attempt to establish rate into squeeze holes; pressured up to 800# and held. C. Thomas, BLM representative, approved procedure change.

Plug #2 with 7 sxs Type III cement (9 cf) inside casing from 1363' to 1079' to cover the Nacimiento top.

TOH and LD tubing. Perforate 2 bi-wire squeeze holes at 173'. Establish rate out bradenhead with 5 bbls of water. SDFD.

11/30/05 **Plug #3** mix and pump 54 sxs Type III cement (71 cf) down 2.875" casing and circulate good returns out bradenhead from 173' to surface.

Shut in well and WOC. SDFD.

ND BOP. Dig and chip out cement around wellhead. Cut off wellhead. Mix 20 sxs Type III cement and install P&A marker. RD and MOL.

C. Thomas, Cuba BLM representative, was on location.