

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB No 1004-0137
Expires March 31, 2007

SUNDRY NOTICES AND REPORTS ON WELLS
**Do not use this form for proposals to drill or to re-enter an
abandoned well. Use Form 3160-3 (APD) for such proposals.**

5. Lease Serial No
NMNM-36096

6 If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE - Other instructions on page 2

7. If Unit of CA/Agreement, Name and/or No.

1 Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

8 Well Name and No
San Isidro No. 12-11

2 Name of Operator
Pride Energy Company

9. API Well No.
30-043-20912

3a Address
PO Box 701950
Tulsa, OK 74170-1950

3b Phone No. (include area code)
Bureau of Land Management
(918) 524-9200,ington Field Office

10. Field and Pool or Exploratory Area
Rio Puerco

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
SL 2372' FWL & 2290' FSL
Unit B, Sec 12- T20N-R3W

11 Country or Parish, State
Sandoval Co., NM

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

| TYPE OF SUBMISSION | TYPE OF ACTION | | | |
|------------------------------------------------------|-----------------------------------------------|------------------------------------------------------|----------------------------------------------------|-----------------------------------------|
| <input checked="" type="checkbox"/> Notice of Intent | <input type="checkbox"/> Acidize | <input type="checkbox"/> Deepen | <input type="checkbox"/> Production (Start/Resume) | <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Subsequent Report | <input type="checkbox"/> Alter Casing | <input type="checkbox"/> Fracture Treat | <input type="checkbox"/> Reclamation | <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Final Abandonment Notice | <input type="checkbox"/> Casing Repair | <input type="checkbox"/> New Construction | <input type="checkbox"/> Recomplete | <input type="checkbox"/> Other _____ |
| | <input type="checkbox"/> Change Plans | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Temporarily Abandon | |
| | <input type="checkbox"/> Convert to Injection | <input type="checkbox"/> Plug Back | <input type="checkbox"/> Water Disposal | |

13 Describe Proposed or Completed Operation. Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

Propose to P & A. Plugging procedure is attached

RCVD FEB 18 '08

OIL CONS. DIV.

DIST. 3

14 I hereby certify that the foregoing is true and correct.

Name (Printed/Typed)
Larry Miller

Title Engineer

Signature

Date 01/31/2008

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Original Signed: Stephen Mason

Title

Date

FEB 15 2008

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon

Office

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction

(Instructions on page 2)

NMOCDC

SAN ISIDRO NO. 12-11

PLUGGING PROCEDURE:

1. RUPU. PULL PRODUCTION EQUIPMENT.
2. RU WIRELINE. SET 7" CIBP @ 3300' +/- AND CAP W/ ¹⁰⁰40' CMT. (~~TOP~~ 7" casing shoe OF LINER)
3. RUN 2-3/8" TUBING TO TOP OF CMT. PLUG AND CIRCULATE HOLE W/ 9.0 PPG MUD. ^{1739'} ^{1639'}
4. PULL TBG TO 4400' AND SPOT 100' PLUG FROM 4400' TO 1000'.
5. PULL TBG TO 400' AND SPOT 100' PLUG FROM 400' TO 300'.
6. PULL TBG TO 50' AND SPOT CEMENT PLUG FROM 50' TO SURFACE.
7. CUT OFF CASING 3' BELOW GROUND LEVEL.
8. WELD ON CAP & ERECT STANDARD NEW MEXICO P&A MARKER.
9. CLEAN & RESTORE LOCATION.

Plg PC/Fr/Kc/OA - 873' - 485'

**UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
FARMINGTON DISTRICT OFFICE
1235 LA PLATA HIGHWAY
FARMINGTON, NEW MEXICO 87401**

Attachment to notice of
Intention to Abandon:

Re: Permanent Abandonment
Well: 12-11 San Isidro

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 599-8907.
3. The following modifications to your plugging program are to be made:
 - a) Bring the top of the Gallup plug to 3200'
 - b) Place the Mesaverde plug from 1739' – 1639'.
 - c) Place the Pictured Cliffs/Fruitland/Kirtland/Ojo Alamo plug from 873' - 485'.

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.