

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

N. Mex. 03451-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Duff-Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Undesignated P.C.

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 27-24N-1W

12. COUNTY OR PARISH 13. STATE

Rio Arriba New Mex

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

TRANS DELTA OIL & GAS CO., INC.

3. ADDRESS OF OPERATOR

1008 Ridglea Bank Bldg., 6300 Ridglea Pl., Ft. Worth, Tex 76116

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

990' from South line, 990' from West line

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

GL 7369'

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

We propose to Plug and Abandon on or about October 21, as follows:

1. Spot 15-sack cement plug inside 5-1/2" casing from 2800' to 3020' covering across perforations 3058' - 3070'.
2. Cut off casing at estimated 2100'. Spot 50-sack cement plug on top of 5-1/2" casing stub. Plug 2075'-2125'.
3. Pull casing. Spot 15-sack cement plug across surface casing shoe from 280' to 330'.
4. Spot surface plug in surface casing from 0' to 30' and install standard dry hole marker.
5. Clean up location, restore surface.
6. Work to start on or about October 21, 1974.

Reason for Abandonment - Lease Terminated.

18. I hereby certify that the foregoing is true and correct

SIGNED

*M. P. E. fur*

TITLE

Treasurer

DATE

10-14-74

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

\*See Instructions on Reverse Side