

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

MM-03010

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

John S. Doshko "B"

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Devils Fork Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREASE/4 SE/4 Section 11,
T-24-N, R-7-W

12. COUNTY OR PARISH

Rio Arriba

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	2. NAME OF OPERATOR PAN AMERICAN PETROLEUM CORPORATION	3. ADDRESS OF OPERATOR 301 Airport Drive, Farmington, New Mexico 87401
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' FSL & 990' FSL	14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6935' GL, 6947' RDS

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

As a result of the above mentioned well's failure to produce economical quantities of oil, we plan to plug and abandon it in the following manner:

1. Circulate casing with mud.
2. Set cement retainer at 5860' and squeeze 25 sacks Class "A" Neat cement into Gallup perfor 5959-5966'.
3. Spot 50 sacks Class "A" neat cement from 4350' to 3900'.
4. Spot 5 sacks Class "A" neat cement from 40' to surface.
5. Squeeze 15 sacks Class "A" neat cement into 5-1/2" - 8-5/8" casing annulus.
6. Cut off wellhead, erect FIA marker, and clean up location.



RECEIVED

APR 17 1968

U. S. GEOLOGICAL SURVEY
FARMINGTON, N.M.

18. I hereby certify that the foregoing is true and correct

Original Signed By

SIGNED C. W. EATON, JR.
C. W. Eaton, Jr.TITLE Area EngineerDATE April 10, 1968

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963—O-685229

8-57-851

