

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	State <input type="checkbox"/> Federal <input type="checkbox"/>
5. State Oil & Gas Lease No.	

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSAL TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</small>	
1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name Canyon Largo Unit
2. Name of Operator El Paso Natural Gas Company	8. Form or Lease Name Canyon Largo Unit
3. Address of Operator PO Box 990, Farmington, NM 87401	9. Well No. 93 (P&A)
4. Location of Well UNIT LETTER <u>A</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM THE <u>East</u> LINE, SECTION <u>12</u> TOWNSHIP <u>25N</u> RANGE <u>6W</u> N.M.P.M.	10. Field and Pool, or Wildcat So. Blanco P.C.
5. Elevation (Show whether DF, RT, GR, etc.) 6702'GL	12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	TESTING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING (PNS) <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work) SEE RULE 1103.

Due to non-production it is planned to plug and abandon this well in the following manner:

Spot a 30 sack cement plug to cover perf (2820-2844').

Shoot off 2 7/8" casing at free point and spot a 20 sack cement plug on casing sub.

If cut off is made below the base of the Ojo Alamo, spot a 35 sack cement plug over the Ojo Alamo.

Spot a 15 sack cement plug at base of surface casing.

Spot a 10 sack cement plug at the surface with a Plug & Abandon marker, clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed S. H. Wood TITLE Petroleum Engineer DATE October 4, 1971

APPROVED BY Emmy C. C. C. TITLE SUPERVISOR DATE OCT 5 1971

CONDITIONS OF APPROVAL, IF ANY: