14. PERMIT NO.

UNITED STATES DEPARTMENT OF THE INTERIOR

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

New Mexico

DEPARIMENT OF THE INTERIOR verse side)	5. LEASE DESIGNATION AND SERIAL NO.
GEOLOGICAL SURVEY	Contract #150
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)	6. IF INDIAN, ACLOTTEE OR TRIBE NAME Jicarilla Apache
1. OIL GAS WE'LL WELL OTHER	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR	8. FARM OR LEASE NAME
Southern Union Production Company	Jicarilla "0"
3. ADDRESS OF OPERATOR	9. WELL NO.
P.O. Box 808, Parmington, New Mexico 37401	2
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface	10. FIELD AND POOL, OR WILDCAT Tapacito Pictured Cliff
1555 Ft. from the North line and 955 ft. from the best line.	11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA SEC. 1, T-26N, R-5W N.M.P.M.

7388 Foet OF Rio Arribe

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:			
FRACTURE TREAT MUL SHOOT OR ACIDIZE ABA	LTIPLE COMPLETE ANDON* ANGE PLANS	WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING (Other) (Note: Report results of multiput Completion or Recompletion Rep	REPAIRING WELL ALTERING CASING ABANDONMENT* Die completion on Well ort and Log form.)		

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Due to uneconomic status of the Jicarilla 'G" No. 2, it is therefore intended to plug and abandon the subject well as follows:

- 1. Rig up pulling unit. (Note: No tubing in hole.)
- 2. Put class "A" cement plug @ 4050 ft. to P.B.T.D. 4171 ft.
- 3. Shoot 4 holes at 3850 ft. and squeeze 25 sks.
- 4. Put 100 ft. plus 3100 ft. in side pipe.
- 5. Cut off 5-1/2", 15.5% casing and set 100 feet plug on cut off 50 ft. in and 50 ft. out.
- 6. Put 50 ft. coment plug at 204 ft.
- Put 10 ft. coment plug) surface and set dry hole marker.
- 8. Restore location.

18.	I hereby certify that the foregoing is true and correctly SIGNED JIE Bongventura	TITLE	Production Superintendent	DATE	October	1,	1976
	(This space for Federal or State office use)						
	APPROVED BYCONDITIONS OF APPROVAL, IF ANY:	TITLE.		DATE			

Clas

*See Instructions on Reverse Side

JK