		· · · · · · · · · · · · · · · · · · ·
orm 3160-5	A section of the participation of the section of th	FORM APPROVED
une 1990)	to the second of the second of the	Budget Bureau No. 1004-0135
ine 1970)	and the second s	Expires: March 31, 1993
UNI	FED STATES	5. Lease Designation and Serial No.
	T OF THE INTERIOR	SF-078067
	LAND MANAGEMENT	6. If Indian, Allottee or Tribe Name
SUNDRY NOTICES	AND REPORTS ON WELLS	
	frill or to deepen or reentry to a different reservoir	7. If Unit or CA. Agreement Designation
	OR PERMIT" for such proposals	
SUBMI	TIN TRIPLICATE	Carson Unit
1. Type of Well	والمراقبة والمرا	8. Well Name and No.
X Oil Well Gas Well Other		,34-14
2. Name of Operator		9. API Well No.
Central Resources, Inc.		,30-045-05335
3. Address and Telephone No.		10. Field and Pool, or Exploratory Area
P.O. Box 1247, Bloomfield, New Mexico 87413 (505)-632-3476		Bisti Lower Gallup
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		11. County or Parish, State
660' FSL, 1980' FEL, Sec 14, T25N, R12W		San Juan, New Mexico
	) TO INDICATE NATURE OF NOTICE, REI	PORT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACT	
	X Abandonment	I Change of Plans
X Notice of Intent	Recompletion	New Construction
	Plugging Back	Non-Routine Fracturing
Subsequent Report	Casing Repair	water Shut-Off
	Altering Casing	Conversion to Injection
Final Abandonment Notice	Other	Dispose Water
		(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
there is evidence cement is in p Proposed Procedure:  A Notify the Farmington I B. Pull all retreivable down C. Set a CIBP at 4865 and a D. Set a 100' cement plug for E. Set a 100' cement plug for E.	lace behind the casing.  3LM office at 505-599-8907 24 hours prior t	78' inside and outside 4 1/2" casing 1232' inside and outside 4 1/2"casing.
G. Set a cement plug from		ng shoe at 104' inside and outside 4 1/2" casir
G. Set a cement plug from H. Cut wellhead and instal	surfacer to 54' to 154' across the surface casi I dry hole marker. Clear and remediate locat  Title Production Tech.	ng shoe at 104' inside and outside 4 1/2" casin
G. Set a cement plug from H. Cut wellhead and instal  14. I he Patty Shelton Si (This space for Federal or State off  Conditions of approval, if any:	surfacer to 54' to 154' across the surface casi I dry hole marker. Clear and remediate locat  Title Production Tech.  Title  Title	ing shoe at 104' inside and outside 4 1/2" casi ion.  Date January 23, 2001