

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. SF080088	
2. NAME OF OPERATOR MARTIN Oil & Gas Co.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR 4705 North 32nd Place, PHOENIX 18, ARIZONA		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 800' FNL 990' FNL Sec 1, T25N, R11W SAN JUAN Co. New Mexico		8. FARM OR LEASE NAME MEKEE	
14. PERMIT NO.		9. WELL NO. 1	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6445 DF		10. FIELD AND POOL, OR WILDCAT WILDCAT	
		11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA Sec 1 T25N, R11W N.M.	
		12. COUNTY OR PARISH SAN JUAN	
		13. STATE N.M.	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	☐	PULL OR ALTER CASING	☒
FRACTURE TREAT	☐	MULTIPLE COMPLETE	☐
SHOOT OR ACIDIZE	☐	ABANDON*	☒
REPAIR WELL	☐	CHANGE PLANS	☐
(Other)	☐		☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	☐	REPAIRING WELL	☐
FRACTURE TREATMENT	☐	ALTERING CASING	☐
SHOOTING OR ACIDIZING	☐	ABANDONMENT*	☐
(Other)	☐		☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is INTENDED to plug and ABANDON this well as follows:

1. Squeeze pack 523265418
2. Cut & Pull 5 1/2" Casing
3. Place Cement Plug 50' in and 50' over Casing Stub
4. Place 100' Cement Plug from 2300 to 2400
5. Place 100' Cement Plug from 1550 to 1650
6. Erect P & A MARKER w/ 10' Surface Plug
7. CLEAN UP LOCATION.

This well is UNECONOMICAL to Produce.



18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: