

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

SF-078896

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Mudge Federal

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

29-27N-11W

NMPM

12. COUNTY OR PARISH

San Juan

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL ☐ GAS ☐
WELL WELL OTHER ☒

2. NAME OF OPERATOR

Beta Development Co.

3. ADDRESS OF OPERATOR

125 Petroleum Plaza, Farmington, N.M. 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1850/S 1850/W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6184.5' G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plug and abandon well:

Rig up, pull tubing, lay down any tubing with holes, run tubing back to bottom squeeze 50 sacks cement into 4½" casing perforations @ 6355-77', spot 25 sacks cement plug on top of casing perforations, pull tubing up holes and spot 25 sacks across 2 stage collar @ 1953'. Shoot and recover 4½" casing below Ojo-Alamo base @ 750', spot 50 sacks cement 50' in and 100' out of casing stub, if this plug is below Ojo Alamo spot 30 sacks at base of Ojo-Alamo spot 25 sacks @ 200' put 10 sacks in top with dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

D. E. Burt

TITLE

Superintendent

DATE

2-10-78

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Olaf