Form	3	160-5
Clune	1	990)

Type of Well Oil Well

Name of Operato

Address and Telephone No

Gas Well

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 3 1 ,1993 Lease Designation and Seriai No.

JUL 30 1998

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

NM 04202 SUNDRY NOTICES AND REPORTS ON WELLS 6. If Indian, Allonee or Tribe Name Use "APPLICATION FOR PERMIT—" for such proposals 7. If Unit or CA, Agreement Designation SUBMIT IN TRIPLICA TE 8. Well Name and No. Johnston LS #5 **CONOCO INC** 30-045-07551 10 DESTA DR. STE. 100W, MIDLAND, TX. 79705-4500 (915) 686-5424 10 Field and Pool, or Exploratory Area 4 Location of Well (Footage, Sec., T. R. M. or Survey Description) Blanco Mesaverde Section 9, T-28-N, R-9-W, N 11. County or Parish, State 890' FSL & 1600' FWL San Juan, NM CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF ACTION Abandonment Change of Plans

TYPE OF SUBMISSION Notice of Intent Recompletion New Construction Subsequent Repon Plugging Back Non-Routine Fracrunng Casing Repair Water Shut-Off Final Abandonment Notice Altering Casing Conversion to Injection Dispose Water INote: Reponresuitsof multiplecompitiononWdl
Completion or Recompletion Report and Log form.)

Describe Proposed or Completed Operations (Clearly state ail pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to complete the following work on this well:

- 1. RU
- 2. Clean out, install plunger lift
- 3. Return to production

011 GON. DIV. DIST, R

APR 01 1999 HIS APPROVAL EXPIRES

Kay Maddox Regulatory Agent July 18 1998 Title

Title

BLM(6), NMOCD(1), SHEAR, PONCA; COST ASST, FILE ROOM

/S/ Duane W.

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its junsdiction

Johnston LS 5 Plunger Lift Installation Procedure

- 1. Hold safety meeting. MIRU workover unit. If necessary, kill well with a minimum of 1% KCL. NU BOP and TIH and tag for fill. POOH w/ 2.374" tubing.
- 2. If necessary, RIH w/ 5.5" bit and scraper. RU Power swivel and clean out to PBTD. POOH w/ bit & scraper.
- 3. RIH w/ 2.375" production tubing land SN at \pm /- 5157'.
- 4. Install Plunger.
- 5. Install &/or hook up any necessary flowline, separation, and metering equipment.
- 6. Return well to MV production.

7. Thank You.

Prepared by:

Dah-Ruey Chi Summer Engineer

ox Political