

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIP
(Other instructions
reverse side)

TE-
re

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		5. LEASE DESIGNATION AND SERIAL NO. SF 080238	
2. NAME OF OPERATOR Dugan Production Corp.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR Box 208, Farmington, NM 87401		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1850' FNL - 1850' FEL		8. FARM OR LEASE NAME Gee Gee	
14. PERMIT NO.		9. WELL NO. 2	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5853' GL		10. FIELD AND POOL, OR WILDCAT Wildcat	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 31 T27N R12W	
		12. COUNTY OR PARISH San Juan	
		13. STATE NM	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	(Other) <input type="checkbox"/>

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Request permission to plug and abandon this well in the following manner:

1. Fill 2-7/8" O.D., 6.5#, J-55, 8R, EUE casing from 1270' GL to surface using 34 sx cement.
2. Install permanent dry hole monument.
3. Fill all pits.
4. Clean well location of all equipment, pipe, junk, and trash.
5. Accomplish surface restoration as specified by the surface management agency or land owner.
6. Cut or remove tie-downs.

Bradenhead Squeeze 2 7/8" x 5 1/2" annulus with cement to cover 5 1/2" surface casing shoe at 36'. Spot plug from 86' to surface in annulus to cover surface casing shoe.

18. I hereby certify that the foregoing is true and correct

SIGNED <i>Sherman E. Dugan</i>	TITLE Agent	DATE 1-25-82
(This space for Federal or State office use)		
APPROVED BY <i>Jim Sims</i>	TITLE District Supervisor	DATE 1-25-82
CONDITIONS OF APPROVAL, IF ANY:		

NMOCC

*See Instructions on Reverse Side