

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐ Temporarily Abandoned		5. LEASE DESIGNATION AND SERIAL NO. SF 08065	
2. NAME OF OPERATOR El Paso Natural Gas Company		6. IF INDIAN ALLIANCE OR RESERVATION RECEIVED	
3. ADDRESS OF OPERATOR Box 990, Farmington, New Mexico 87401		7. UNIT AGREEMENT NAME JUL 28 1970	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1750'S, 990'W		8. FARM OR LEASE NAME OIL CON. COM.	
14. PERMIT NO.		9. WELL NO. 1 (P&A)	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5855' CL		10. FIELD AND POOL, OR WILDCAT Aztec Plugged Cliffs	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 13, T-29-N, R-10-W	
		12. COUNTY OR PARISH N. M. P. M.	
		13. STATE San Juan New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐

PULL OR ALTER CASING ☐

WATER SHUT-OFF ☐

REPAIRING WELL ☐

FRACTURE TREAT ☐

MULTIPLE COMPLETE ☐

FRACTURE TREATMENT ☐

ALTERING CASING ☐

SHOOT OR ACIDIZE ☐

ABANDON* ☒

SHOOTING OR ACIDIZING ☐

ABANDONMENT* ☐

REPAIR WELL ☐

CHANGE PLANS ☐

(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

On 9-28-61 this well was temporarily abandoned by spotting a 50 sacks cement plug from 2105' to 2279'. (38' of open hole and 75' in 7" Casing).

Due to non-production it is planned to plug and abandon this well in the following manner:

Let casing free point of 7" casing by stretch. Shoot casing off above free point and spot a 30 sack cement plug by displacing down the casing.

Pull 7" casing. Place a 25 sack cement plug across base of surface casing.

Place a 10 sack cement plug at surface, install a 4' x 4" dry hole marker and clean location.

NOTE: If free point is above the top of the Ojo Alamo (1114') perforate at 1215' (base of the Ojo Alamo) before shooting casing off and spot a 50 sack cement plug inside 7" casing at 1215' and pressure displace through perforations ~~about~~ about 20 sacks.

18. I hereby certify that the foregoing is true and correct

SIGNED Original Signed E. H. WOOD

TITLE Petroleum Engineer

DATE 7-24-70

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

*See Instructions on Reverse Side

RECEIVED

JUL 28 1970

U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated in Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between, and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.