

5-OCC
2-Getty
1-JTHampton
1-HLKendrick
1-F NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NO. OF COPIES RECEIVED	4
DISTRIBUTION	1
SANTA FE	1
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Beta Development Co. 3. Address of Operator 125 Petroleum Club Plaza, Farmington, N.M. 87401 4. Location of Well UNIT LETTER O 790 FEET FROM THE South LINE AND 1850 FEET FROM THE East LINE, SECTION 23 TOWNSHIP 30 N RANGE 12 W NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 5512' GR	7. Unit Agreement Name 8. Farm or Lease Name Hughlett Smith 9. Well No. 1 10. Field and Pool, or Wildcat Flora Vista Mesaverde 12. County San Juan
--	--

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug & abandon, as follows:

Load hole w/water, circ. & CO to 3420'. Spot 50 sx cement on bottom & squeeze approx. 20 sx cement into all Mesaverde csg perforations. Pull tbg up hole to D.V. tool @ 1933', pump in 15 sk plug; pull tbg out of hole, cut & pull all free 4-1/2" csg. Go back in hole w/tbg & put 15 sk plug in csg stub & 25 sk plug in open hole above csg stub. Put 10 sx in bottom of surface pipe @ 315', put 10 sx in top of surface pipe w/marker.

Place 25 sacks at base of the Ojo Alamo formation.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by
D. E. BAXTER

SIGNED _____ TITLE Superintendent DATE January 16, 1970

APPROVED BY _____ TITLE _____ DATE 1-16-70

CONDITIONS OF APPROVAL, IF ANY: