

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Schumacher
3. Address of Operator Box 990, Farmington, New Mexico - 87401	9. Well No. 4
4. Location of Well UNIT LETTER P, 990 FEET FROM THE South LINE AND 990 FEET FROM East LINE, SECTION 18 TOWNSHIP 30N RANGE 10W NMPM.	10. Field and Pool, or Wildcat Aztec Pictured Cliffs
15. Elevation (Show whether DF, RT, GR, etc.) 6419' GL	12. County San Juan

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐  
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-production it is planned to plug and abandon this well as follows:

Spot a 30 sk. cement plug on bottom to cover open hole 2923-3057'.

Perforate 4 holes at the base of the Ojo Alamo at 1693' and spot a <sup>50</sup> sack cement plug across perforations & displace 30 sacks Through perforations

Determine free point of 5 1/2" casing and cut off. Spot a <sup>50</sup> sack cement plug on top of casing stub, pull casing & ~~plug~~

Spot a 30 sack cement plug at base of surface casing.

Place a 10 sack cement plug at the surface w/a 4' x 4" P & A marker.

Clean location.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Original Signed E. H. Wadell</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>8-29-69</u>
APPROVED BY <u>Emory Church</u>	TITLE <u>Sup. Dist. III</u>	DATE <u>9-3-69</u>
CONDITIONS OF APPROVAL, IF ANY:		