

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals

5. Lease Designation and Serial No.
SF-081239

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
L. C. Kelly 4

9. API Well No.
Basin Dakota

10. Field and Pool, or Exploratory Area
3004509830

11. County or Parish, State
San Juan New Mexico

1. Type of Well
 Oil Well Gas Well Other

2. Name of Operator Attention:
Amoco Production Company Lois Raeburn

3. Address and Telephone No.
P.O. Box 800, Denver, Colorado 80201 (303) 830-5294

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1098 FSL 975 FWL Sec. 03 T 30N R 12W

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other _____
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*
Amoco Production Company request permission to Plug and Abandon the above mentioned well.

See attachment for procedures .

If you have any questions please contact Lois Raeburn @ (303) 830-5294

RECEIVED
JUL 08 1994

RECEIVED
 DISTRICT MANAGER
 JUL 08 1994
 O/O DISTRICT MANAGER, NM

14. I hereby certify that the foregoing is true and correct.
Signed *Lois Raeburn* Title Business Assistant Date 06-30-1994

(This space for Federal or State office use)
Approved by _____ Title _____
Conditions of approval, if any:

APPROVED AS AMENDED

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

JUL 06 1994
DISTRICT MANAGER

PXA Procedures
L C Kelly #4

1. Check location for anchors. Install if necessary. Test anchors.
2. MIRUSU. Blow down well. Kill if necessary with fresh water. NDWH. NUBOP.
3. Squeeze perfs at 6646' to 6724' thru packer at 6609' with cuft cement. Place 100' plug on top of packer. (cuft cement) Place 9ppg mud to 4535'.
4. RIH with short string CBL and determine TOC. Depending on TOC, RIH with perf gun and shoot squeeze holes at the following depths and displace cement 100' inside and outside casing and place mudd between plugs:

Pictured Cliffs at 2143'
Fruitland Coal at 1812'
Ojo Alamo at 639'

5. Perf at 639' and circulate to surface with cuft cement. Displace cement inside casing to surface with cuft cement.
6. NDBOP. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
7. Turn over to John Schwartz for reclamation.
8. Rehabilitate location according to BLM or State requirements.