

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>			5a. Indicate Type of Lease State <input type="checkbox"/> Federal <input type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator El Paso Natural Gas Company			5. State Oil & Gas Lease No.
3. Address of Operator PO Box 990, Farmington, NM 87401			7. Unit Agreement Name
4. Location of Well UNIT LETTER <u>G</u> <u>1840</u> FEET FROM THE <u>North</u> LINE AND <u>1840</u> FEET FROM THE <u>East</u> LINE, SECTION <u>15</u> TOWNSHIP <u>30N</u> RANGE <u>9W</u> NMPM.			8. Farm or Lease Name Riddle A
15. Elevation (Show whether DF, RT, GR, etc.) 6367'GL		9. Well No. 7 (P&A)	10. Field and Pool, or Wildcat Undes. Farmington
16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data		12. County San Juan	

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK

TEMPORARILY ABANDON

PULL OR ALTER CASING

OTHER _____

PLUG AND ABANDON

CHANGE PLANS

SUBSEQUENT REPORT OF:

REMEDIAL WORK

COMMENCE DRILLING OPNS.

CASING TEST AND CEMENT JOB

OTHER _____

ALTERING CASING

PLUG AND ABANDONMENT

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production, it is planned to plug and abandon this well in the following manner:

Spot a 55 sack cement plug to cover from 2508' to 1775' which will cover the perforations and approximately 70' above the Ojo Alamo inside the casing (Ojo Alamo was covered on primary cement job).

Shoot off 4 1/2" casing and pull casing. Spot a 50 sack cement plug on the casing stub.

Spot a 25 sack cement plug at base of surface casing.

Spot a 15 sack cement plug at the surface with a Plug & Abandon marker, clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED HH Wood TITLE Petroleum Engineer DATE October 13, 1971

APPROVED BY Ernest Chavez TITLE Sup. Dist. III DATE 11-2-71

CONDITIONS OF APPROVAL, IF ANY: