
State of New Mexico Form C-103 Submit 3 Copies Energy, Minerals and Natural Resources Department to Appropriate Revised 1-1-89 District Office OIL CONSERVATION DIVISION DISTRICT WELL API NO. P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 Santa Fe. New Mexico 87504-2088 P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease FEE X STATE DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410 6. State Oil & Gas Lease No. SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) Type of Well: Mobil WELL X WELL | 2. Name of Operator 8. Well No. Joel B. Burr, #1 9. Pool name or Wildcat 3. Address of Operator P.O. Box 50, Farmington, N.M. 87499 Flucher Kutz Well Location South 765 West M 540 Feet From The Unit Letter Line Feet From The 12W San Juan Section NMPM County Towaship 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 5704 GR Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK **ALTERING CASING** PLUG AND ABANDONMENT TEMPORARILY ABANDON **CHANGE PLANS** COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JOB **PULL OR ALTER CASING** OTHER: OTHER: 12. Describe Proposed of Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Plug as per the attached procedure DEC2 0 1991 OIL CON, DIV. I hereby certify that the information above is true and complete to the best of my knowledge and beilef. 12/20/91 SIONATURE _ Joel B. Burr, Jr. TYPE OR PRINT NAME TELEPHONE NO. (This space for State Use) DEC 2 0 1991

DEPUTY OIL & GAS INSPECTOR, DIST. #2

CONDITIONS OF AFFROYAL, IF ANY:

Original Signed by CHARLES GHOLSON



December 11, 1991

Mobil #1 Well Flug & Abandonment Procedure M. 540' FSL, 765' FWL Sec. 21, T30N, R12W San Juan County, NM

Proposed Procedure:

- 1. Move cementing truck on location; blow well down.
- ND wellhead and install cementing head.
- 3. Establish pump rate into perforations.
- 4. Pump Plug #1 from 1806' to surface with 50 sxs Class B neat cement.
- 4. Shut in well and WOC overnight.
- 5. Tag cement in 2-7/8" casing and fill to surface if necessary.
- 6. Cut off 7" and 2-7/8" casings below ground level and install P&A marker.
- 7. Remove fence, fill in pits and reclaim location.

