

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <b>Dry Hole</b>		5. LEASE DESIGNATION AND SERIAL NO. <b>1420-600-3340</b>
2. NAME OF OPERATOR <b>Slocally Oil Company</b>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME <b>Mountain Tribal</b>
3. ADDRESS OF OPERATOR <b>Box 730 - Hobbs, New Mexico</b>		7. UNIT AGREEMENT NAME <b>-</b>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <b>740' PSL &amp; 1910' PML Sec. 26-32N-17W</b>		8. FARM OR LEASE NAME <b>Navajo "P"</b>
14. PERMIT NO.		9. WELL NO. <b>13</b>
15. ELEVATIONS (Show whether DF, RT, GR, etc.) <b>5860' DF</b>		10. FIELD AND POOL, OR WILDCAT <b>Harry Rocco Gallup</b>
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <b>Sec. 26-32N-17W</b>
		12. COUNTY OR PARISH <b>San Juan</b>
		13. STATE <b>New Mexico</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

No commercial zones of oil or gas was encountered in any zone of this well. This well was Temporarily Abandoned on September 29, 1963. We now plan to Plug and Abandon this well in the following manner:

1. Move in and rig up pulling unit.
2. Displace hole with heavy mud.
3. Spot 25 sack cement plug from 1770' to 1690'.
4. Fill hole with heavy mud laden fluid.
5. Spot 10 sacks of cement in top of 7-5/8" OD casing.
6. Install 4" steel dry hole marker.

RECEIVED

OCT 14 1965

U. S. GEOLOGICAL SURVEY  
FARMINGTON, N. M.

Note: Please send approved copy to the above address.

RECEIVED

OCT 14 1965

18. I hereby certify that the foregoing is true and correct

SIGNED **(ORIGINAL) H. E. Aab**

TITLE **Dist. Superintendent**

DATE **October 12, 1965**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE