

(SUBMIT IN TRIPLICATE)

Land Office 100-100-100
Lease No. 100-100-100
Unit 100-100-100

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

NOTICE OF INTENTION TO DRILL	SUBSEQUENT REPORT OF WATER SHUT-OFF
NOTICE OF INTENTION TO CHANGE PLANS	SUBSEQUENT REPORT OF SHOOTING OR ACIDIZING
NOTICE OF INTENTION TO TEST WATER SHUT-OFF	SUBSEQUENT REPORT OF ALTERING CASING
NOTICE OF INTENTION TO RE-DRILL OR REPAIR WELL	SUBSEQUENT REPORT OF RE-DRILLING OR REPAIR
NOTICE OF INTENTION TO SHOOT OR ACIDIZE	SUBSEQUENT REPORT OF ABANDONMENT
NOTICE OF INTENTION TO PULL OR ALTER CASING	SUPPLEMENTARY WELL HISTORY
NOTICE OF INTENTION TO ABANDON WELL	

(INDICATE ABOVE BY CHECK MARK NATURE OF REPORT, NOTICE, OR OTHER DATA)

Well No. 100-100-100 is located 100 ft. from S line and 100 ft. from W line of sec. 10
100-100-100 (Twp.) 100 (Range) 100 (Meridian)
100-100-100 (Field) 100-100-100 (County or Sub-division) 100-100-100 (State or Territory)

The elevation of the derrick floor above sea level is 100 ft.

DETAILS OF WORK

(State names of and expected depths to objective sands; show sizes, weights, and lengths of proposed casings; indicate mudding jobs, cementing points, and all other important proposed work)

Plan to pull the 1" tubing in the well, cement free with approximately 10,000 gallons of oil and 10,000 lbs of sand and then return the 1" tubing.

I understand that this plan of work must receive approval in writing by the Geological Survey before operations may be commenced.

Company 100-100-100

Address 100-100-100

100-100-100

By 100-100-100

Title 100-100-100

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

MINUTES IN TRIPLICATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-81424.

SUNDRY NOTICES AND REPORTS

(Do not use this form for proposals to drill or to deepen or plug; use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐

2. NAME OF OPERATOR
Southern Union Production Company

3. ADDRESS OF OPERATOR
P. O. Box 806, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface
560 ft. from the South line and 1980 ft. from the West line.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)
7491 ft. D.F.

6. LEASE DESIGNATION AND SERIAL NO.
I-22-2nd-2772

8. IF INDIAN, ALLOTTEE OR TRIBE NAME
UTE MOUNTAIN TRIBE

7. UNIT AGREEMENT NAME
OF INDIANS

8. FARM OR LEASE NAME
Barber Dome

9. WELL NO.
6

10. FIELD AND POOL, OR WILDCAT
Barber Creek Pool

11. SEC., T., R., E., OR S.W., AND SURVEY OF AREA
Sec. 10, T-34N, R-7E, S. 14E

12. COUNTY OR PARISH
San Juan

13. STATE
New Mexico

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON ☒
CHANGE PLANS ☐

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT ☐

(Note: Report results of multiple completion on "Well Completion or Recompletion Report and Log form.")

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We propose to plug and abandon this well. The well is located low on the structure and is presently non-productive.

PLUGGING PROCEDURE:

1. Set cement plug over Dakota formation from total depth of 3252 ft. - 3050 ft. using 50 sacks of cement. Top of cement will be 100 ft. up in bottom of 5-1/2" casing.
2. Fill 5-1/2" casing w/9.0#/gal mud from 3050 ft. to 1200 ft.
3. Perf. 2 holes in 5-1/2" casing at 1200 ft. Cement thru holes w/150 sacks of cement to set plug in annulus behind 5-1/2" casing from 1200 ft. to 1000 ft. Displace cement in 5-1/2" casing to 1150 ft. leaving 50 ft. of cement above perforations inside 5-1/2" casing.
4. Set 5 sacks cement plug in top of 5-1/2" casing from 10 ft. to surface.
5. All of 5-1/2" casing will be left in well.
6. Erect dry hole marker, clear location and abandon well.

RECEIVED

MAR 13 1970

U. S. GEOLOGICAL SURVEY
DURANGO, COLO.

18. I hereby certify that the foregoing is true and correct

SIGNED **GILBERT D. NOLAND, JR.**

TITLE

Drilling Superintendent

DATE

March 12, 1970

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side