

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE\*  
(Other instructions on re-  
verse side)Form approved  
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

NM-020982

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Summit Viles "B"

9. WELL NO.

#6

10. FIELD AND POOL, OR WILDCAT

Fulcher Kutz Pictured Cliff

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 29-T29N-R11W

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐
2. NAME OF OPERATOR  
Aztec Oil & Gas Company
3. ADDRESS OF OPERATOR  
P.O. Drawer 570, Farmington, New Mexico 87401
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

530' FSL &amp; 990' FFL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GC, etc.)

5431' GR

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR A TEE CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

X

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

## PROPOSE TO:

Determine free point of 2-7/8" production casing. Shoot casing off above  
free point.

Spot 50' cement plug across perfs.


Perforate squeeze hole in 4-3/4" casing opposite base of Ojo Alamo.

Squeeze with 50 sacks cement. Spot 50' plug inside casing across squeeze holes.

Squeeze bradenhead with 25 sacks cement.

Spot 10' plug at surface.

Install dry hole marker and clean up location.



18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Production Manager DATE August 11, 1977

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side