

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

3a. Indicate Type of Lease
State ☐ Fee ☒

3. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Southland Royalty Company	8. Farm or Lease Name McDaniel
3. Address of Operator P.O. Drawer 570, Farmington, New Mexico 87499	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>230</u> FEET FROM THE <u>North</u> LINE AND <u>280</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>29N</u> RANGE <u>11W</u> NMPM.	10. Field and Pool, or Wildcat Fulcher Kutz PC
15. Elevation (Show whether DF, RT, GR, etc.) 5523' GL	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	Revised* PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SOUTHLAND ROYALTY COMPANY hereby proposes to plug and abandon the subject well in the following manner:

- 1) Rig up and pull 1" pipe.
- 2) Establish rate down 3-1/2" casing and pump 80 sacks cement with 3% CaCl₂ (94 cu.ft.). Displace to 510'. Shut In and allow to set.
- 3) Shot squeeze hole to 510'.
- *4) Pump 69 sacks (82 cu.ft.) cement with 3% CaCl₂ with 41 sacks squeezed out squeeze hole to cover Ojo Alamo at 336'. Remaining volume will fill casing to surface.
- *5) Cut off casing and dump cement to fill to surface.
- *6) Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Petroleum Engineer DATE 11-10 83

APPROVED BY Original Signer: J. L. ROSE CHOLSON TITLE DEPUTY COMMISSIONER DATE NOV 15 1983

CONDITIONS OF APPROVAL, IF ANY: