

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. OG-935	
7. Unit Agreement Name -----	
8. Farm or Lease Name Shell State	
9. Well No. 2	
10. Field and Pool, or Wildcat Flying "M" (SA)	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Coastal States Gas Producing Company
3. Address of Operator P. O. Box 2498, Abilene, Texas
4. Location of Well UNIT LETTER 0 659.3 FEET FROM THE South LINE AND 1985.3 FEET FROM THE East LINE, SECTION 9 TOWNSHIP 9-S RANGE 33-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4382.6' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well will be plugged and abandoned as follows:

1. Spot 25 sk plug across perforations 4527-31'.
2. Cut 5-1/2" casing at 3500' (top cement) and pull.
3. Spot 25 sk plug at 5-1/2" stub.
4. Spot 25 sk plug at 349', base 8-5/8" casing.
5. Spot 10 sk plug in surface.
6. Install marker and clean location.

→ 25 SKS @ Top of Salt

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>Joe P. Howard</i></u>	TITLE <u>Production Supt.</u>	DATE <u>June 28, 1965</u>
APPROVED BY <u><i>Joe P. Howard</i></u>	TITLE <u>SECRETARY</u>	DATE <u>JUL 1 1965</u>
CONDITIONS OF APPROVAL, IF ANY:		