

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <u>Dry Hole</u>	7. Unit Agreement Name
2. Name of Operator <u>Tenneco Oil Company</u>	8. Farm or Lease Name <u>Bonds, F.C.</u>
3. Address of Operator <u>P.O. Box 1031 Midland Texas 79701</u>	9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>20</u> TOWNSHIP <u>9S</u> RANGE <u>35 E</u> NMPM.	10. Field and Pool, or Wildcat <u>Vada Penn Ext</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>4165 GR</u>	12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set cement plug 9830' - 9655' (50 SX)
2. Set Cement plug 4140' - 3960' (50 SX) across bottom 8 5/8" CSG.
3. Cut 8 5/8" casing at 1000'± and pull to recover
4. Set 50 SX cement plug 50' below to 50' above 8 5/8" stub.
5. Set 50 SX cement plug at surface.
6. Erect dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED L. M. Williams TITLE Production Engineer DATE 4-10-69

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT DATE APR 10 1969

CONDITIONS OF APPROVAL, IF ANY: