

COPIES RECEIVED		
CONTRIBUTION		
TAX FEE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
-----	
7. Unit Agreement Name	
-----	
8. Farm or Lease Name	
Baker "A"	
9. Well No.	
3	
10. Field and Pool, or Wildcat	
-----	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole
2. Name of Operator Skelly Oil Company
3. Address of Operator P. O. Box 1351, Midland, Texas 79701
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>26</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3324 DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was plugged and abandoned December 29, 1945. Due to possible waterflows via this wellbore, it has been recommended that this well be replugged and abandoned to meet current standards.

- 1) Move in workover rig.
- 2) Drill surface plug and clean out to 2384'.
- 3) Set 50 sack cement plug 2284-2384'.
- 4) Set 50 sack cement plug 900-1000'.
- 5) Set 60 sack cement plug surface to 60'.
- 6) Set dry hole marker.

NOTE: All intervals not cemented will be filled with 10.2# mud.

*January 15, 1975*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED (Signed) D. R. Crow D. R. Crow TITLE Lead Clerk DATE 1-15-75

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 19 1975

U.S. CONSERVATION COMM.  
MOORE, H. M.