# NM OIL CONSERVATION

ARTESIA DISTRICT

District 1 1625 N. French Dr., Hobbs, NM 88 APR 0 1 2015 Energy Minerals and Natural Resources District II

Form C-129 Revised August 1, 2011

811 S. First St., Artesia, NM 88210 District III 1000 Rio Brazos Road, Aztec, NM 87 RECEIVED District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

Oil Conservation Division 1220 South St. Francis Dr. Santa Fe, NM 87505

Submit one copy to appropriate District Office

NFO Permit No. (For Division Use Only)

#### **APPLICATION FOR EXCEPTION TO NO-FLARE RULE 19.15.18.12** (See Rule 19.15.18.12 NMAC and Rule 19.15.7.37 NMAC)

A.	Applicant COG Operating LLC , whose address is One Concho Center, 600 W Illinois Ave, Midland, TX 79701 ,		
			hereby requests an exception to Rule 19.15.1
	June 28 , Yr 2015 , for the following described tank battery (or LACT):  Name of Lease Shoeless Joe 32 State Name of Pool Bone Spring		
			Location of Battery: Unit Letter D
	Number of wells producing into battery <u>4, 30-015-40586, 30-015-41238, 30-015-41028, 30-015-41242</u>		
	B.	Based upon oil production of 670	barrels per day, the estimated * volume
		of gas to be flared is	MCF; Valueper day.
C.	Name and location of nearest gas gathering f	acility:	
D.	DistanceEstimated cost of connection		
E.	This exception is requested for the following reasons: Line pressure issues		
	·		
OPERATOR I hereby certify that the rules and regulations of the Oil Conservation		OIL CONSERVATION DIVISION	
	een complied with and that the information given above plete to the best of my knowledge and belief.	Approved Until	
Signature	S: V.:	By	
Printed Name & Title Brian Maiorino		Title	
	ess bmaiorino@concho.com	Date	
Date 3/30/15	Telephone No. 432-221-0467		

Gas-Oil ratio test may be required to verify estimated gas volume.

## NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

#### CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator: COG OPPRATING

Well Name & Number: ETZ State Unit 1/9

API #: 30-0/5-2/333

- 1. Produced water will not be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.
- 8. Cement Retainers may not be used.
- 9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
- 10. Plugs may be combined after consulting with and getting approval from NMOCD.
- 11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: 4/2/2015

APPROVED BY:

### GUIDELINES FOR PLUGGING AND ABANDONMENT

#### DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub
  plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
  - o Fusselman
  - o Devonian
  - o Morrow
  - o Wolfcamp
  - o Bone Spring
  - o Delaware
  - o Any Salt Section (Plug at top and bottom)
  - o Abo
  - o Glorieta
  - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).