Form 3160 (April 200

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

OCD ARTESIA

FORM APPROVED OMB NO. 1004-0137 Expires March 31, 2007

Lease Serial No.

EIVED SIMM254

RECEIVED

Do not use this form for proposals to drill or to re-enter an CD - ARTESIA abandoned well. Use Form 3160-3 (APD) for such proposals.

6/ If Indian, Allottee or Tribe Name

			<u>_</u>	4	
SUBMIT IN TRIPLICATE - Other instructions on reverse side 181311				7. If Unit or	CA/Agreement, Name and/or No
Type of Well Oil Well Gas Well Other Name of Operator				8. Well Name Foster 31	
Nearburg Producing Company				#1	
3a. Address 3300 N A St., Bldg 2, Ste 120, Mid	land, TX 79705	3b. Phone No. (<i>include at</i> 432/686-8235	•	9. API Well No. 30-015-21851 10. Field and Pool, or Exploratory Area	
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 660 FSL and 1980 FWL, Sec 31-19S-25E				Dagger Draw; Upper Penn, North	
				11. County	or Parish, State
				Eddy	NM_
12. CHECK APPROPRIATE	BOX(ES) TO INI	DICATE NATURE OF	NOTICE, REP	ORT, OR O	THER DATA
TYPE OF SUBMISSION	TYPE OF ACTION				
X Notice of Intent	Acidize	Deepen	Production	n (Start/Resume)	Water Shut-Off
Subsequent Report	Alter Casing Casing Repair	Fracture Treat New Construction	Reclamati		Well Integrity Other TA
Final Abandonment Notice	Change Plans Convert to Injecti	Plug and Abandon Plug Back	Temporar Water Dis	ily Abandon	Extension
Describe Proposed or Completed Operation (clear	ly state all pertinent deta	ils, including estimated starti	ng date of any pr	oposed work an	
If the proposal is to deepen directionally or recome Attach the Bond under which the work will be pe					

If the proposed of Completed Operation (clearly state an perturbed details, including estimated starting date of any proposed work and approximate duration thereof.

If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones.

Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.)

NPC requests extension on subject TA due to NPC's activity in the Yeso in this field.

Accepted for record

SEE ATTACHED FUR CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct Name (Printed/Typed)	Title	
Sarah Jordan	Prod/ Reg Analyst ACCEPTED FOR	2 2 2 2
1 Valada	Prod/ Reg Analyst ACCEPTED FO	RECORD
THIS SPACE FO	R FEDERAL OR STATE OFFICE USE	0000
Approved by	Title Bate 2 U	2006
Conditions of approval, if any, are attached. Approval of this notice doe certify that the applicant holds legal or equitable title to those rights in which would entitle the applicant to conduct operations thereon.	s not warrant or Office	NGRAM NGINEER

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 505-234-5972

Temporary Abandonment of Wells on Federal Lands Conditions of Approval

A temporarily abandoned well is defined as a completion that is not capable of production in paying quantities but which may have value as a service well. Pursuant to 43 CFR 3162.3-4 (c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Temporary Abandonment (TA) status approval requires a successful mechanical or casing integrity test as follows:

- 1. A Notice of Intent (NOI) Sundry Notice (Form 3160-5) requesting approval to run a mechanical integrity test (MIT) or casing integrity test (CIT).
- 2. A description of the temporary abandonment procedure.
 - a. A bridge plug or packer must be installed as close to 50 feet above any open perforations or open hole as possible. If a cement plug is used, the top of the cement must be verified by tagging.
 - b. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leakoff.
 - c. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
 - d. A bradenhead test must be conducted. If the test indicates a problem exists, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
 - e. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County, 505-234-5972; Lea County 505-393-3612.
- 3. Provides justification why the well should be temporarily abandoned rather than permanently plugged and abandoned and an estimated date that the well will be returned to beneficial use or plugged and abandoned.

Wells that successfully pass the casing integrity test will be approved for Temporary Abandonment (TA) status for a 12 month period provided that the operator:

- Submits a subsequent Sundry Notice (Form 3160-5) requesting TA approval.
- 2. Describes the temporary abandonment procedure.
- 3. Attaches a clear copy or the original of the pressure test chart.

The TA status could be extended for an additional 12 month period without another casing integrity test provided there was no leak-off during the test and the test was witnessed by a BLM representative. The operator must submit a sundry notice requesting an extension of TA status 30 days prior to expiration of the previous approval and appropriate justification for extending the TA status is included.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- 1. A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.