

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Oil Cons.
N.M. DIV-Dist. 2
1301 W. Grand Avenue
Artesia, NM 88210

FORM APPROVED
Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM70215

6. If Indian, Allottee or Tribe Name

N/A

7. If Unit or CA, Agreement Designation

SOUTH LONE WOLF

8. Well Name and No.

SOUTH LONE WOLF UNIT #1

9. API Well No.

30-005-62896

10. Field and Pool, or Exploratory Area

Southwest Lone Wolf Dev.

11. County or Parish, State

Chaves

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

ELK OIL COMPANY

3. Address and Telephone No.

P. O. Box 310
Roswell, New Mexico 88202-0310

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Section 29, Township 13 South, Range 29 East
2310' FNL & 1980' FWL

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Check Report number of multiple completion on Well Completion or Recompletion Report and Log Form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work)*

Intend to plug and abandon well as follows:

- (1) Set cement plug at 9574'-9474'.
- (2) Set cement plug at ~~750~~-7650'. 7800'
- (3) Set cement plug at 5695'-5595'. - perf + squeeze @ 5695'
- (4) Cut and pull 2100' of 5 1/2" casing.
- (5) Set cement plug 50 in / 50 out casing stub and 8 5/8" shoe 2159'-2050'.
- (6) Set cement plug 352'-252' (13 3/8 shoe plug 50 in / 50 out.)
- (7) Set 10 sxs surface plug.
- (8) Place mud between all plugs.
- (9) Install dry hole marker.
- (10) Clean up location.

Estimated TOC behind 5 1/2" = 6920'

14. I hereby certify that the foregoing is true and correct

Signed

Title

President

Date

9/24/03

(This space for Federal or State office use)

Approved by

Title

P.F.

Date

10/2/03

Conditions of approval, if any.

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

* See Instruction on Reverse Side

F3160-5.wks

SEE ATTACHED FOR
CONDITIONS OF APPROVAL