August 1999)- DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT MAY 1 4 2009	EXPIRES: NOVEMBER 30, 2000
SUNDRY NOTICES AND REPORTS ON WELLS	5. Lease Serial No.
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals	NM-77046 6. If Indian, Allottee or Tribe Name
SUBMIT IN TRIPLICATE	=
OODINIT IN THE EIGHT	7. Unit or CA Agreement Name and No.
1a Type of Well Oil Well Gas Well Other	
	8 Well Name and No.
2. Name of Operator	North Pure Gold 9 Federal 7.
DEVON ENERGY PRODUCTION COMPANY, LP	9. API Well No.
3. Address and Telephone No.	30-015-27515
20 North Broadway, Oklahoma City, OK 73102 405-235-3611	10. Field and Pool, or Exploratory
4. Location of Well (Report location clearly and in accordance with Federal requirements)*	Los Medanos; Delaware
1980' FNL 660' FWL SEC 9 T23S R31E (9'80	12. County or Parish 13. State
	Eddy NM
CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPOR	
TYPE OS SUBMISSION TYPE OF ACTION	
Y Notice of Intent	on (Start/Resume) Water Shut-Off
☐ Alter Casing ☐ Fracture Treat ☐ Reclama ☐ Subsequent Report ☐ Casing Repair ☐ New Construction ☐ Recomple	
Change Plans Plug and Abandon V Tempora	arily Abandon
Final Abandonment Notice Convert to Injection Plug Back Water D	•
deepen directionally or recomplete honzontally, give subsurface location and measured and true vertical depths of all pertinent markers and zones, the Bond No on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirement, including determined that the site is ready for final inspection).	e operation results in a multiple completion or recompletion in a new
	•
,	
4/22/09 - 4/29/09	•
MIRU PU. MIRU VISUWELL scan 1" & 7/8" rods out of hole. RD VISUWELL. RIH w/ ro	
NU BOP. POOH w/ tbg. RIH w/ CIBP w/ tbg. Set CIBP @ 7000'. POOH w/ tbg. LD cs	
leaking. Dump cmt on CIBP. TOC @ 6965'. RIH w/ tbg. CHC w/ 2% w/ pkr fluid. POO	OH LD tog. ND BOP. NU WH. RDMO.
RUN chart. Test csg to 590#, for 30 min.	
ACCEPTED FOR RECORD	Subsect to.
ACCEPTED FUN NECOND	) UDVEC ! . U.
<del> </del>	1-11/450
	ATTACHED COA'S
MAY 1 5 2009	00110
/s/ JD Whitlock Ji	COA3.
75/ 05 **********************************	•
BUREAU OF LAND MANAGEMENT	
SEE ATTACHED FOR CARLSBAD FIELD OFFICE	
1	Accepted for record
CONDITIONS OF APPROVAL	NMOCD RE
14. I hereby certify that the foregoing is true and correct	

Judy A. Barnett Regulatory Analyst

Date

Date

5/6/2009

Name Title

Title

(This space for Federal or State Office use)

Approved by Conditions of approval, if any.

Doopped 50 PS/ Failed Test

## BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

## Temporary Abandonment of Wells on Federal Lands Conditions of Approval

A temporarily abandoned well is defined as a completion that is not capable of production in paying quantities but which may have value as a service well. Pursuant to 43 CFR 3162.3-4 (c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Temporary Abandonment (TA) status approval requires a successful mechanical or casing integrity test as follows:

- 1. A Notice of Intent (NOI) Sundry Notice (Form 3160-5) requesting approval to run a mechanical integrity test (MIT) or casing integrity test (CIT).
- 2. A description of the temporary abandonment procedure.
  - a. A bridge plug or packer must be installed as close to 50 feet above any open perforations or open hole as possible. If a cement plug is used, the top of the cement must be verified by tagging.
  - b. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leakoff.
  - 5. ac. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
  - d. A bradenhead test must be conducted. If the test indicates a problem exists, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
    - e. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity, Test. For wells in Eddy County, 575-361-2822; Lea County 575-393-3612.
- 3. Provides justification why the well should be temporarily abandoned rather than permanently plugged and abandoned and an estimated date that the well will be returned to beneficial use or plugged and abandoned.

Wells that successfully pass the casing integrity test may be approved for Temporary Abandonment (TA) status provided that the operator:

- Submits a subsequent Sundry Notice (Form 3160-5) requesting TA approval with well bore diagram.
- 2. Describes the temporary abandonment procedure.
- 3. Attaches a clear copy or the original of the pressure test chart.
- 4. Give justification to allow well to be place in TA status and plan for future use of well with time frame that well will be place back on line or plans to P&A well will be submitted.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- 1. A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.

North Pure Gold 9 Federal #7. Submit Subsequent Report and well bore diagram with all Perforations and CIBP with tops of cement. Well may be approved to be TA for a period of 1 year after successful MIT and subsequent report is submitted.