

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

NM OIL CONS. COMMISSION
Form approved
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ P&A	5. LEASE DESIGNATION AND SERIAL NO. NM 39765
2. NAME OF OPERATOR Yates Petroleum Corporation	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 207 South 4th St., Artesia, NM 88210	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980 FSL & 1980' FEL, Sec. 23-T3S-R14E	8. FARM OR LEASE NAME Bonita ZC Federal
14. PERMIT NO.	9. WELL NO. 1
15. ELEVATIONS (Show whether DE, RT, GR, etc.) 5750' - 6225' GR	10. FIELD AND POOL, OR WILDCAT Wildcat Precambrian
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Unit J, Sec. 23-3S-14E
	12. COUNTY OR PARISH Lincoln
	13. STATE NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Propose to plug and abandon well as follows:

- 1) Notify BLM 24 hours in advance of plugging.
- 2) Cover perfs 1547-51' and 1661-65' w/minimum 35 sx cement plug and tag.
- 3) Cover perfs 1210-16' w/minimum 35 sx cement plug and tag.
- 4) Set 35 sx cement plug in 5 1/2" from 620-520' to cover shoe 10-3/4" at 570'.
- 5) Set 15 sx cement plug and set dry hole marker.
- 6) Notify BLM that location cleaned and ready for inspection.

* 35 sx cmt. plug across perfs 2030-48'. Tag plug - as discussed w/ Nelson Muncie of Yates Pet. Corp. P.W.C. 6/11/84

18. I hereby certify that the foregoing is true and correct

SIGNED Peter W. Chester TITLE Production Supervisor DATE 6-6-84

(This space for Federal or State official use)
(Orig. Sgd.) PETER W. CHESTER

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

JUN 11 1984

*See Instructions on Reverse Side