

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

*clst
dp*

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

JAN - 8 '90

WELL API NO.
30-015-26062

5. Indicate Type of Lease
STATE FEE

6. State Oil & Gas Lease No.
VB-298

SUNDRY NOTICES AND REPORTS ON WELLS O. C. D.
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name
Foothills AGH State

1. Type of Well:
OIL WELL GAS WELL OTHER P&A

8. Well No.
1

2. Name of Operator
YATES PETROLEUM CORPORATION

9. Pool name or Wildcat
Wildcat

3. Address of Operator
105 South 4th St., Artesia, NM 88210

4. Well Location
Unit Letter 0 : 660 Feet From The South Line and 2310 Feet From The East Line
Section 20 Township 19S Range 23E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4046.4' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

1. Pull tubing and packer, set CIBP approximately 3800' w/cement cap.
2. Cut 5 1/2" casing approximately 3700', spot 100 sx Class "C" cement at 3700-3400', pull casing to 1650'. Spot 50 sx Class "C" at 1650-1450' (across 8-5/8" shoe and top of Glorieta). Pull casing to 50'. Spot 10 sx Class "C" at surface. Install dry hole marker.
3. Clean location as per State requirements. Approval to P&A given by Mike Williams NMOCD, Artesia, NM, 11-6-89.

*Post ID-2
1-19-90
P4A*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Juanita Goodlett TITLE Production Supervisor DATE 1-5-90

TYPE OR PRINT NAME Juanita Goodlett TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE Field Rep DATE 10/13/93

CONDITIONS OF APPROVAL, IF ANY: