

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-23005
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 648
7. Lease Name or Unit Agreement Name Eddy AV State Com
8. Well Number 1
9. OGRID Number 26460
10. Pool name or Wildcat Winchester Wolfcamp (Gas)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator
SABRE OPERATING, INC.

3. Address of Operator
P.O. BOX 4848 WICHITA FALLS, TX 76308-0848

4. Well Location
Unit Letter L : 1980 feet from the South line and 660 feet from the West line
Section 27 Township 19S Range 28E NMPM County Eddy

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3357

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☒ Change Pool Name

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Propose to plug back the Morrow and recomplete in the **Winchester Wolfcamp (Gas)**. Below is the planned procedure.

1. Release packer trip out of hole.
2. GIH set cast iron bridge plug at approximately 10,500', Dump 20' of cement on top.
3. Run cement bond log to check cement, top of cement, and locate hole in casing.
4. RIH tubing, set packer at approximately 8800'.
5. Perforate 8886' - 8910' and W/4 SPF.
6. Acidize with 2500 gallons 15% NEFE HCL acid.
7. Swab test.

NM OIL CONSERVATION
ARTESIA DISTRICT
NOV 22 2017
RECEIVED

Spud Date:

9-14-2017

Rig Release Date:

10-11-2017

Approval for Burton Plat WC, North (gas) 10-3-2017

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Donelle Field TITLE Secretary DATE 11-20-17

Type or print name _____ E-mail address: _____ PHONE: _____
For State Use Only

APPROVED BY: [Signature] TITLE Staff Mgr DATE 12-28-17