

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

N. M. O. C. C. COPY
NOV 10 1969
 NEW MEXICO OIL CONSERVATION COMMISSION
C. C. C.
ARTESIA, OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Federal <input type="checkbox"/>
5. State Oil & Gas Lease No. 080982
7. Unit Agreement Name
8. Farm or Lease Name Gorman Federal
9. Well No. 1
10. Field and Pool, or Wildcat Bitter Lakes S.A. South
12. County Chaves

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Petroleum Corporation of Texas
3. Address of Operator P. O. Box 911, Brackenridge, Texas 76024
4. Location of Well UNIT LETTER <u>A</u> <u>330</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM THE <u>East</u> LINE, SECTION <u>27</u> TOWNSHIP <u>10 S</u> RANGE <u>25 E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3510' Top of csg.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Casing record: 7" @ 0' - 728' W/300 sx. cement circulated.
 4½" @ 0' - 980' W/250 sx. cement circulated.

Perforations: 930' - 969' TD: 980'

Proposed plugging procedure.

- (1) Dump 7 sx. cement 910'-980'
- (2) Fill hole with 10.0 mud.
- (3) Put 1.5 sx. cement 0'-14'.
- (4) Set 4" x 4" Steel marker.

Level location and fill pits.

You will be notified as to the time and date that each plug will be set so that you may have a representative present to witness same.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Billy D. Moore TITLE Production Clerk DATE November 4, 1969
 APPROVED BY [Signature] TITLE _____ DATE _____
 CONDITIONS OF APPROVAL, IF ANY: _____

RECEIVED

NOV 10 1969

U. S. GEOLOGICAL SURVEY
 ARTESIA, NEW MEXICO

RECEIVED

NOV 13 1969

C. C. C.
ARTESIA, OFFICE